

plantronics®

**LEARN
MORE**

K100™ Bluetooth® In-car Speakerphone


TAKE A GOOD LOOK

MULTI-FUNCTION BUTTON

- Power on or off (3- to 4-second press)
- Take a call or end it (1 tap)
- Redial (2 taps)
- Transfer audio to or from phone during call (3-second press)
- Reject a call (press and hold until you hear a single tone)
- Initiate phone's voice-dialing (2-second press until second tone is heard)
- Activate manual pairing (with power off, press and hold until LED flashes red/blue)
- Reconnect lost Bluetooth connection (1 tap)
- Enable/disable missed call indicator (1 tap)

FM BUTTON

- FM transmit on or off (2- to 4-second press, release when beep is heard)
- Find FM channel (press and hold until station option is announced)
- Tune to a nearby free channel (tap to increase, double-tap to decrease)



LED

- Charging (solid red)
- Powering on or off (2 blue or red flashes)
- FM transmission (2 purple flashes)
- Missed call (1 purple flash)
- Pairing mode (red/blue flashes)

VOLUME WHEEL

- Increase volume (rotate clockwise)
- Decrease volume (rotate counterclockwise)

MUTE BUTTON


- Mute on or off (1 tap)
- Night mode: LED on or off (2-second press until tone is heard)

MICRO USB CHARGING PORT

- With micro USB or car charger: 2.5 hours (100% charge)
- Best performance when fully charged

Be safe! Please read the safety guide for important safety, charging, battery and regulatory information before using your new speakerphone.

CONNECT TO YOUR PHONE



1. READY

Activate the Bluetooth feature on your phone, then use the phone's settings to add/search/discover new Bluetooth devices.

iPhone: Settings > General > Bluetooth > On
(starts the search for devices)



BlackBerry® smartphone:
Settings/options > Bluetooth: On > Search for devices



2. SET

First time:

With speakerphone turned off, activate Bluetooth pairing mode by pressing and holding the Multi-function button to turn on speakerphone. The LED flashes red/blue to indicate pairing mode.



3. CONNECT

Select "PLT_K100" from the list of Bluetooth devices shown on your phone.

If the phone asks for a passcode, enter four zeros (0000). You may see **** on screen.

Some phones also ask to confirm the connection after pairing.

The speakerphone LED will stop flashing red/blue once your phone is successfully paired/connected.


"Pairing" is the process that connects the speakerphone to your phone. You can pair more phones but can have only one active connection at a time.

HEAR CALLS THROUGH YOUR CAR STEREO


You can listen to calls through your car stereo speakers by transferring the audio from the speakerphone to a free FM channel between 88.1 and 107.9 MHz.

If your phone is A2DP-enabled you can also hear streaming audio like GPS instructions and music through your car speakers.

We recommend that you transfer audio to an FM channel before you start driving, and that you make a routinely clear channel a preset on your stereo.



Suggested placement



1. READY

Ensure that your phone and speakerphone are powered on and connected.

2. SET

Press the FM button to enter FM transmit mode. One of nine preset FM channels will be announced.

3. CONNECT

Manually set your radio to the announced FM channel. If that channel is in use by a radio station, then press the FM button to hear another channel option. Tune your radio to the new channel. You are now ready to transmit calls and streaming audio like GPS directions from your phone to your car stereo.

Alternatively, tune your radio to a free channel with decimal ending 1, 3, 5, 7, 9 and between 88.1 and 107.9 MHz. Then tune the speakerphone to same channel using the FM button (tap to increase, double-tap to decrease).

If a radio station suddenly takes over the FM channel, press the FM button for 2-4 seconds (release when beep is heard) to redirect the audio back through the speakerphone.

NOTE The FM transmit mode will automatically switch off if there is no audio transmitted (calls or music/GPS) for more than 1 minute, when this occurs FM buzzing/white noise may be heard via the car stereo. The FM transmitter will re-connect automatically once the audio device is re-activated.

LISTEN TO THE VOICE

This speakerphone announces various status alerts when you power on/off, run low on talk time, or lose/reconnect the Bluetooth connection to your phone.

WHAT YOU'LL HEAR	WHEN YOU'LL HEAR IT
Power on	After pressing the Multi-function button for 3 to 4 seconds
Power off	After pressing the Multi-function button for 3 to 4 seconds
Battery low	When you have less than an hour left before the battery must be recharged
Pairing	While the speakerphone and phone are trying to pair/connect
Pairing incomplete	After the speakerphone and phone tried to pair but failed
Lost connection	When the phone and speakerphone lose the Bluetooth connection
Call terminated	After ending a call or when using the call back feature through visual voice mail
Volume maximum	After reaching the highest volume setting
Connected	After turning the speakerphone on or reconnecting a dropped Bluetooth connection
Mute on	After tapping the Mute button
Mute off	From muted, after tapping the Mute button
FM on channel XX.X	After pressing the FM button, FM transmission turns on and the voice announces the current station it is using
FM channel XX.X	After pressing and holding the FM button, the voice announces the channel it now uses
FM off	From on, after pressing the FM button to turn transmission off

TIPS

Keep your eyes on the road:

The controls are easy to find with your fingertips without looking for them.

Before driving, reach up and familiarise yourself with the controls so you can keep your eyes on the road when a call comes in.

- The notched Volume wheel is easy to feel.
- The Multi-function button is inside the wheel.
- The Mute button has a raised notch.

Avoid a dead battery:

Remember to power off the speakerphone when you exit your car. If you forget, the speakerphone will automatically turn off after 90 minutes of not having an active connection.

Protect your hearing:

You can adjust the volume faster by turning the volume wheel faster. To adjust the volume a small amount, turn the wheel slowly.

Connect easily:

When powering on, the speakerphone searches for the last connected phone.

Turn the LED on or off:

For comfortable night driving, you can turn the lights on or off by pressing and holding the Mute button for 2 seconds until you hear a tone.

Listen to the voice (in English only):

This speakerphone says various status alerts when you power on/off, lose/reconnect the Bluetooth connection to your phone, or change FM channels.

Sound your best:

Clip the speakerphone to your visor where the two microphones, located on the top of the unit, can be closest to your face so you can speak in a normal tone of voice and be heard.

SPECIFICATIONS

Talk time	Up to 17 hours
Standby time	Up to 15 days
Operating distance (range)	Up to 10 meters (33 feet) from phone
Speakerphone weight	92 grams
Speakerphone dimensions	120 x 60 x 16.5mm (without clip)
Charge connector	Micro USB connector
Battery type	Rechargeable, non-replaceable Lithium-ion polymer
Charge time (maximum)	2.5 hours to full charge
Power requirements	5V DC - 500mA
Bluetooth version	2.1 with EDR and eSCO
Bluetooth profiles	Hands-Free (HFP) 1.5, Headset (HSP) 1.1 and Advanced Audio Distribution (A2DP)
Operating, storage and charging temperature	-10°C – 50°C (14°F – 122°F)

NEED MORE HELP?

en

Plantronics Ltd
Wootton Bassett, UK
Tel: 0800 410014

ar

منطقة الشرق الأوسط
لمزيد من المعلومات:
+44 (0)1793 842443*

cs

Czech Republic
+44 (0)1793 842443*

da

Danmark
Tel: 80 88 46 10

de

Plantronics GmbH
Hürth, Deutschland
Kundenservice:
Deutschland 0800 9323 400
Österreich 0800 242 500
Schweiz 0800 932 340

el

Για περισσότερες
πληροφορίες:
+44 (0)1793 842443*

es

Plantronics Iberia, S.L.
Madrid, España
Tel: 902 41 51 91

fi

Finland
Tel: 0800 117095

fr

Plantronics Sarl
Noisy-le-Grand
France
Tel: 0800 945770

ga

Plantronics BV
Regus House
Harcourt Centre
Harcourt Road
Dublin 2, Ireland
Service ROI: 1800 551 896

he

למידע נוסף, בקר באתר:
+44 (0)1793 842443*

hu

További információk:
+44 (0)1793 842443*

it

Plantronics Acoustics
Italia Srl, Milano, Italia
Numero Verde: 800 950934

nl

Plantronics B.V.
Hoofddorp, Nederland
NL 0800 7526876
BE 0800 39202
LUX 800 24870

no

Norge
Tel: 80011336

pl

Aby uzyskać więcej informacji:
+44 (0)1793 842443*

pt

Portugal
Tel: 0800 84 45 17

ro

Pentru informații
+44 (0)1793 842443*

ru

Дополнительная
информация:
+44 (0)1793 842443*

sv

Sverige
Tel: 0200 21 46 81

tr

Daha fazla bilgi için:
+44 (0)1793 842443*

*Support in English

www.plantronics.com

NEED MORE HELP?

Safety information:

see the separate “For Your Safety” booklet

2-year limited warranty details:

www.plantronics.com/warranty

Plantronics B.V.
Scorpius 140
2132 LR Hoofddorp
Netherlands
www.plantronics.com

© 2010 Plantronics, Inc. All Rights Reserved. Plantronics and K100 are trademarks or registered trademarks of Plantronics, Inc. The Bluetooth word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by Plantronics, Inc. is under license. iPhone is a trademark of Apple Inc. registered in the U.S. and other countries. Blackberry is owned by Research In Motion Limited and is registered in the United States and may be pending or registered in other countries. Plantronics, Inc is not endorsed, sponsored, affiliated with or otherwise authorized by Research In Motion Limited.
AM84444-03 (11/10)



EEE Yönetmeliğine Uygundur