





QUICK START

POLY STUDIO P21
PLASTIC SPEAKER COVER

CONTENTS




Pry Tool




(10) Plastic Speaker Cover


REMOVE FABRIC COVER 1




2





3



ATTACH PLASTIC COVER 4



5



www.poly.com/P21



© 2021 Plantronics, Inc. All rights reserved. Poly, the propeller design, and the Poly logo are trademarks of Plantronics, Inc. All other trademarks are the property of their respective owners. Manufactured by Plantronics, Inc.



1725-87489-001A 08.21

