



Upgrade Guide

8.3.0 | December 2014 | 3725-72106-001F

# Polycom® RealPresence® Resource Manager System



---

Copyright© 2014, Polycom, Inc. All rights reserved. No part of this document may be reproduced, translated into another language or format, or transmitted in any form or by any means, electronic or mechanical, for any purpose, without the express written permission of Polycom, Inc.

6001 America Center Drive  
San Jose, CA 95002  
USA



Polycom®, the Polycom logo and the names and marks associated with Polycom products are trademarks and/or service marks of Polycom, Inc. and are registered and/or common law marks in the United States and various other countries. All other trademarks are property of their respective owners. No portion hereof may be reproduced or transmitted in any form or by any means, for any purpose other than the recipient's personal use, without the express written permission of Polycom.



Java is a registered trademark of Oracle America, Inc., and/or its affiliates.

**End User License Agreement** By installing, copying, or otherwise using this product, you acknowledge that you have read, understand and agree to be bound by the terms and conditions of the End User License Agreement for this product. The EULA for this product is available on the Polycom Support page for the product.

**Patent Information** The accompanying product may be protected by one or more U.S. and foreign patents and/or pending patent applications held by Polycom, Inc.

**Open Source Software Used in this Product** This product may contain open source software. You may receive the open source software from Polycom up to three (3) years after the distribution date of the applicable product or software at a charge not greater than the cost to Polycom of shipping or distributing the software to you.

**Disclaimer** While Polycom uses reasonable efforts to include accurate and up-to-date information in this document, Polycom makes no warranties or representations as to its accuracy. Polycom assumes no liability or responsibility for any typographical or other errors or omissions in the content of this document.

**Limitation of Liability** Polycom and/or its respective suppliers make no representations about the suitability of the information contained in this document for any purpose. Information is provided "as is" without warranty of any kind and is subject to change without notice. The entire risk arising out of its use remains with the recipient. In no event shall Polycom and/or its respective suppliers be liable for any direct, consequential, incidental, special, punitive or other damages whatsoever (including without limitation, damages for loss of business profits, business interruption, or loss of business information), even if Polycom has been advised of the possibility of such damages.

**Customer Feedback** We are striving to improve our documentation quality and we appreciate your feedback. Email your opinions and comments to [DocumentationFeedback@polycom.com](mailto:DocumentationFeedback@polycom.com).

**Polycom Support** Visit the [Polycom Support Center](#) for End User License Agreements, software downloads, product documents, product licenses, troubleshooting tips, service requests, and more.

---

# Contents

- Prepare for Polycom® RealPresence® Resource Manager System Upgrade . . . 2**
  - Prepare to Upgrade an Appliance Edition . . . . . 2
    - Review the Release Notes . . . . . 2
    - Request or Locate Current Recovery DVD . . . . . 2
    - Request a Software License Upgrade File . . . . . 2
    - Back Up the RealPresence Resource Manager System . . . . . 3
    - Download Endpoint and Peripheral Software Updates . . . . . 3
  - Prepare to Upgrade a Virtual Edition . . . . . 4
    - Review the Release Notes . . . . . 4
    - Deploy the RealPresence Platform Director System . . . . . 4
    - Back Up the RealPresence Resource Manager System . . . . . 4
    - Download Endpoint and Peripheral Software Updates . . . . . 5
  - Migrating Certificate Settings When Upgrading to 8.3 . . . . . 5
  
- Upgrading a Non-Redundant Polycom Resource Manager System . . . . . 9**
  - Download the Software Upgrade File . . . . . 9
  - Perform the Software Upgrade . . . . . 10
  - License Your Upgraded System . . . . . 10
    - License an Appliance Edition . . . . . 11
    - License a Virtual Edition . . . . . 11
  - Upload Endpoint and Peripheral Software Updates . . . . . 11
  - Verify the Upgrade . . . . . 12
  
- Upgrading a Redundant Polycom RealPresence Resource Manager System . 13**
  - About Redundancy and Upgrading a Redundant RealPresence Resource Manager System 13
    - Request a Software License Upgrade File . . . . . 14
  - Download the Software Upgrade File . . . . . 15
  - Back Up the Redundant System . . . . . 15
  - Reset the Redundant System to be a Standalone Server . . . . . 16
  - Back Up the Standalone System . . . . . 16
  - Perform the Software Upgrade on Both Standalone Servers . . . . . 16
  - Reconfigure the Standalone Servers for Redundancy . . . . . 17
  - Upload the New License File . . . . . 17
  - Verify the Upgrade . . . . . 18

# Prepare for Polycom® RealPresence® Resource Manager System Upgrade

---

This chapter describes the tasks you should do in advance of upgrading the Polycom RealPresence Resource Manager system. The steps vary according if you have the Virtual Edition or Appliance Edition.

- [Prepare to Upgrade an Appliance Edition](#)
- [Prepare to Upgrade a Virtual Edition](#)
- [Migrating Certificate Settings When Upgrading to 8.3](#)

## Prepare to Upgrade an Appliance Edition

Perform the following steps to prepare for upgrading your RealPresence Resource Manager system, Appliance Edition.

- [Review the Release Notes](#)
- [Request or Locate Current Recovery DVD](#)
- [Request a Software License Upgrade File](#)
- [Back Up the RealPresence Resource Manager System](#)
- [Download Endpoint and Peripheral Software Updates](#)

### Review the Release Notes

You should review the release notes for the software version to which you are upgrading. The release notes detail supported upgrade paths as well as a summary of new features, known issues, and resolved issues.

### Request or Locate Current Recovery DVD

Please be sure to carefully follow the documented procedures for the upgrade to ensure success. As with any upgrade, we recommend that the person performing the upgrade has the recovery DVD for the currently installed RealPresence Resource Manager system version available during the upgrade process. With the recovery DVD, you can re-image the system back to its original state and restore the original system data. If needed, contact Polycom Global Services to request a recovery DVD.

### Request a Software License Upgrade File

For appliance editions, you need to first request a software license file to use for your upgrade.

#### To request a software license file:

- 1 In a separate browser page or tab, log into the RealPresence Resource Manager system server as an administrator.
- 2 Go to **Admin > Server Settings > Licenses** and record the RealPresence Resource Manager system server serial number.
- 3 Go to <http://support.polycom.com>.

- 4 In the **Licensing & Product Registration** section, select **Activation/Upgrade**.
- 5 Log in or Register for an Account.
- 6 Select **Site & Single Activation/Upgrade**.
- 7 In the **Site & Single Activation** page, enter the serial number you recorded in step 2.
- 8 Click **Next**.
- 9 Accept the **EXPORT RESTRICTION** agreement.
- 10 In the new **Site & Single Activation** page, enter the serial number listed on your License Certificate and enter the license number (shipped with the product) and click **Activate**.  
If retrieving licenses for a redundant system, repeat this step for each server in your configuration.
- 11 In the **Key Code** field, **click here to download** to retrieve and save your license files.



#### Licensing for a Redundant System

When you have a redundant RealPresence Resource Manager system, you'll need a license file for each system in your configuration. Enter each serial number separately.

## Back Up the RealPresence Resource Manager System

You need to back up the entire system. This process creates a backup archive of the RealPresence Resource Manager system. Once this archive is created, you must immediately continue on to [Upgrading a Non-Redundant Polycom Resource Manager System](#) or [Upgrading a Redundant Polycom RealPresence Resource Manager System](#).

### To backup the RealPresence Resource Manager system:

- 1 From the Resource Manager system web interface, go to **Admin > Maintenance > Backup/Restore System Settings**.
- 2 When the **Backup/Restore System Settings** page appears, click **Create and Download a Backup Archive**.
- 3 In the **Select location for download** dialog box, enter a unique **File name**, browse to a location on your system and click **Save**.



#### Storing the Backup File

Be sure to select a drive that is not on the server used for the RealPresence Resource Manager system. All data on the RealPresence Resource Manager system drive will be deleted during the upgrade process.

A **File Download** dialog box displays the progress of the download operation.

- 4 When the operation is completed, click **OK**.
- 5 Browse to the location specified and verify the file download.

## Download Endpoint and Peripheral Software Updates

If your system has endpoint or peripheral software updates stored on it, you must download those updates so you can restore them after upgrading. They are not retained in the system backup.

If you choose not to download them now and stored them in another location in preparation for the upgrade, You will need to re-upload them from <http://support.polycom.com>.

For more information on these tasks, refer to the *Polycom RealPresence Resource Manager System Operations Guide*.

## Prepare to Upgrade a Virtual Edition

Perform the following steps before upgrading a RealPresence Resource Manager system, Virtual Edition/

- [Review the Release Notes](#)
- [Deploy the RealPresence Platform Director System](#)
- [Back Up the RealPresence Resource Manager System](#)
- [Download Endpoint and Peripheral Software Updates](#)

### Review the Release Notes

You should review the release notes for the software version to which you are upgrading. The release notes detail supported upgrade paths as well as a summary of new features, known issues, and resolved issues.

### Deploy the RealPresence Platform Director System

Before upgrading or installing your product software, be sure that you have already installed RealPresence Platform Director system and verified that your product is licensed.

Virtual Editions of Polycom RealPresence Platform products such as RealPresence Resource Manager require the RealPresence Platform Director system to deploy the software and manage licensing. The RealPresence Platform Director provides the flexibility to deploy, license and monitor the RealPresence Platform, Virtual Edition products using general purpose hardware in an organization's data center or in the cloud.

The RealPresence Platform Director is available at no charge from Polycom's support website.

For complete instructions on how to deploy the RealPresence Platform Director system, Virtual edition, see the *RealPresence Platform Director System Administrator's Guide*.

### Back Up the RealPresence Resource Manager System

You need to back up the entire system. This process creates a backup archive of the RealPresence Resource Manager system. Once this archive is created, you must immediately continue on to [Upgrading a Non-Redundant Polycom Resource Manager System](#).

#### To backup the RealPresence Resource Manager system:

- 1 From the Resource Manager system web interface, go to **Admin > Backup/Restore System Settings**.
- 2 When the **Backup/Restore System Settings** page appears, click **Create and Download a Backup Archive**.
- 3 In the **Select location for download** dialog box, enter a unique **File name**, browse to a location on your system and click **Save**.



### Backup Locations

Be sure to select a drive that is not on the server used for the RealPresence Resource Manager system. All data on the RealPresence Resource Manager system drive will be deleted during the upgrade process.

A **File Download** dialog box displays the progress of the download operation.

- 4 When the operation is completed, click **OK**.
- 5 Browse to the location specified and verify the file download.

## Download Endpoint and Peripheral Software Updates

If your system has endpoint or peripheral software updates stored on it, you must download those updates so you can restore them after upgrading. They are not retained in the system backup.

If you choose not to download them now and stored them in another location in preparation for the upgrade, You will need to re-upload them from <http://support.polycom.com>.

For more information on these tasks, refer to the *Polycom RealPresence Resource Manager System Operations Guide*.

## Migrating Certificate Settings When Upgrading to 8.3

The RealPresence Resource Manager system has simplified certificate (TLS settings) starting with version 8.3. Use this section to help you understand the differences when you upgrade to RealPresence Resource Manager system 8.3.

In versions previous to 8.3, TLS settings were called **Certificate Settings** and divided up into three categories. Certificate Settings are now called TLS Settings and have simpler configuration options.

The following section describes the old settings and how they are now represented in version 8.3.

For previous **Server Settings**, use the following table as guidance:

Previous Field	Description	Differences in Version 8.3
Cipher Mode	You can choose from the following cipher modes: Standard Ciphers Weak Ciphers Strong Ciphers (FIPS)	You can now enable Strong Ciphers without enable FIPS-140. However, when you enable FIPS-140 separately, Strong Ciphers is now automatically selected.

Previous Field	Description	Differences in Version 8.3
Allow self-signed certificate	You can choose to allow a self-signed certificate on the RealPresence Resource Manager system.	Self-signed certificate for the RealPresence Resource Manager server is always allowed in 8.3 and above. The ability to enable or disable this option was removed.
Require client to send certificate	This setting requires all clients (endpoints, peripherals, and users accessing the RealPresence Resource Manager system web interface over an encrypted protocol such as SSL or TLS) to send identity certificates in order to access the system.	This option is now called <b>Validate Certificate Connection from Clients</b> .



For previous External Client Certificate Settings, use the following guidance:

Field	Description	Differences in Version 8.3
Trust self-signed certificate	<p>You can choose to trust self-signed certificates from client systems (endpoints, users accessing the web interface, and peripherals).</p> <p>Use this setting with discretion. Any and all self-signed certificates presented by clients will automatically be installed as trusted peer certificates and will be trusted until they are deleted from RealPresence Resource Manager's trusted certificates list.</p> <p>This setting is intended to be used selectively, for example, during initial deployment of a Polycom solution that will use self-signed certificates going forward. After RealPresence Resource Manager has been running for several hours (or days) and all of the known clients' certificates have been added to the RealPresence Resource Manager's trusted certificates list, the setting should be disabled to prevent network intrusion from unknown clients.</p> <p>Disabling the setting does not mean that self-signed certificates will no longer be trusted. It means that no new self-signed certificates will be automatically added to the RealPresence Resource Manager's trusted certificate list.</p>	<p>This option was removed.</p> <p>You can now manage client certificates by choosing to enable the <b>Validate Certificates for Connections from Clients</b> option.</p>
Validate date range	<p>Choose if you want to validate the date range. When this is checked, the RealPresence Resource Manager verifies the date range contained in the certificate to ensure validity.</p>	<p>This option was removed. Certificates are always validated by date range.</p>
Validate revocation	<p>When this is checked, the RealPresence Resource manager validates the revocation status using the revocation resources (OCSP responder URL or CRL Distribution Point).</p>	<p>This option was removed. Certificates are always validated by revocation status.</p>

For previous External Server Certificate Settings, use the following guidance:

Field	Description	Differences in Version 8.3
Trust self-signed certificate	<p>This option is disabled when the system is in maximum security mode.</p> <p>You can choose to trust self-signed certificates from server systems (DMA systems, MCUS and session border controllers).</p> <p>Use this setting with discretion. Any and all self-signed certificates presented by servers will automatically be installed as trusted peer certificates and will be trusted until they are deleted from RealPresence Resource Manager's trusted certificates list.</p> <p>This setting is intended to be used selectively, for example, during initial deployment of a Polycom solution that will use self-signed certificates going forward. After RealPresence Resource Manager has been running for several hours (or days) and all of the known servers' certificates have been added to the RealPresence Resource Manager's trusted certificates list, the setting should be disabled to prevent network intrusion from unknown servers.</p> <p>Disabling the setting does not mean that self-signed certificates will no longer be trusted. It means that no new self-signed certificates will be automatically added to the RealPresence Resource Manager's trusted certificate list.</p>	<p>This option was removed.</p> <p>You can now manage client certificates by choosing to enable the <b>Validate Certificates for Connections to Servers</b> option.</p>
Validate hostname	<p>When this is checked, the RealPresence Resource Manager verifies the hostname contained in the certificate to ensure validity.</p>	<p>In 8.3 or higher, you can choose to validate the host name of server certificates.</p>
Validate date range	<p>Choose if you want to validate the date range. When this is checked, the RealPresence Resource Manager verifies the date range contained in the certificate to ensure validity.</p>	<p>This option was removed. Certificates are always validated by date range.</p>
Validate revocation	<p>When this is checked, the RealPresence Resource manager validates the revocation status using When this is checked, the RealPresence Resource manager validates the revocation status using the revocation resources (OCSP responder URL or CRL Distribution Point).</p>	<p>This option was removed. Certificates are always validated by revocation status.</p>

# Upgrading a Non-Redundant Polycom Resource Manager System

---

This chapter provides instructions for upgrading a non-redundant Polycom Resource Manager system. See [Upgrading a Redundant Polycom RealPresence Resource Manager System](#) for instructions on upgrading a redundant Polycom Resource Manager system.

Give yourself plenty of time for the system upgrade process. It will take some time, depending on the environment. At some steps you are instructed to wait. **MAKE SURE YOU WAIT UNTIL THE PROCESS IS COMPLETE.** Interrupting the upgrade can corrupt the system.

During the most of the upgrade process, the RealPresence Resource Manager system is offline and all services are unavailable. In addition, the serial console appears inactive; nevertheless, do not power off the system unless instructed to do so.

See the *Polycom RealPresence Resource Manager System Release Notes* for the version to which you are upgrading for information about valid upgrade paths.

**To upgrade to the Resource Manager system software, complete the following tasks:**

- 1 [Download the Software Upgrade File](#)
- 2 [Perform the Software Upgrade](#)
- 3 [License Your Upgraded System](#)
- 4 [Upload Endpoint and Peripheral Software Updates](#)
- 5 [Verify the Upgrade](#)

## Download the Software Upgrade File

Both Appliance and Virtual Editions can be upgraded using the software upgrade file available from Polycom's support website.

**To download the software required to update the system:**

- 1 On your local system, create a directory to which to save the software upgrade file if one does not already exist.
- 2 Using a web browser, go to <http://support.polycom.com>
- 3 In the **Documents and Downloads** section, select the appropriate **Category** (UC Infrastructure) and **Product** (RealPresence Resource Manager) for the required download and click **GO**.  
You'll be taken to the RealPresence Resource Manager system webpage.
- 4 Select the file for the version of software to which you are upgrading.
- 5 You'll be required to submit a confirmation that you have read the RealPresence Resource Manager system End User License Agreement (EULA).  
When the **File Download** dialog box appears, click **Save**.
- 6 When the **Save As** dialog box appears, browse to the directory created in step 1 and click **Save** to save the .bin file to your local system.

- 7 Record the location and name of the saved file.

## Perform the Software Upgrade

The system upgrade process may take up to 45 minutes, depending on the environment. At some steps you are instructed to wait. **MAKE SURE YOU WAIT UNTIL THE PROCESS IS COMPLETE.** Interrupting the upgrade can corrupt the system.

During the upgrade, the RealPresence Resource Manager system is offline and all services are unavailable. In addition, the serial console appears inactive; nevertheless, do not power off the system unless instructed to do so.

The system cannot be upgraded while in HTTPS mode if using Mozilla Firefox. You must either switch the RealPresence Resource Manager system to HTTP or do the upgrade using Microsoft Internet Explorer.

### To upgrade the RealPresence Resource Manager software:

- 1 Go to **Admin > Maintenance > System Log Files** and verify that the **Current Log Level** is set to **Info**.
- 2 Go to **Admin > Maintenance > Server Software Upgrade**.
- 3 From the **Server Software Upgrade** page, click **Upload upgrade file to server** and browse to the location of the upgrade **.bin** file saved in [Download the Software Upgrade File](#).
- 4 Select the **.bin** file and click **Open**.

The **.bin** file uploads to the system.



#### Internet Explorer Recommended

The system cannot be upgraded while in HTTPS mode if using Mozilla Firefox. You must either switch the RealPresence Resource Manager system to HTTP or do the upgrade using Microsoft Internet Explorer.

DO NOT close the upload page while the upgrade is taking place.

- 5 When the system indicates the **File Upload** is **Complete**, click **OK**.
- 6 Click **Upgrade**.  
When the status messages on the upgrade screen start changing ("Stopping services", "applying upgrade", etc.), the upgrade process has started. When the upgrade process is complete, the system reboots.  
DO NOT close the browser while the upgrade is taking place.
- 7 When the upgrade is finished, a dialog displays the following message, **Upgrade Completed. Click to Log In**. You can now log back into the system.
- 8 If you are upgrading a RealPresence Resource Manager system, Virtual Edition previous to 8.2, your system will not be accessible until you add it to the RealPresence Platform Director for licensing and monitoring.

## License Your Upgraded System

Typically, Appliance Editions do not need an upgraded license file. However, the licensing architecture for RealPresence Resource Manager system, Virtual Edition versions 8.2 and higher has changed.

Use the appropriate instructions below:

- [License an Appliance Edition](#)
- [License a Virtual Edition](#)

## License an Appliance Edition

After upgrading your appliance edition, you may need to upload a new licensing file if your upgrade order includes new features. You must use Internet Explorer to access the RealPresence Resource Manager system if you want to upload a new license file.

**To update the license file:**

- 1 Go to **Admin > Server Settings > Licenses**.
- 2 Click **Update License** to view the **Update License** dialog box.
- 3 Click **Choose File** to navigate to the license file you received from Polycom.
- 4 Click **Preview** to preview the license features.
- 5 On the Update License dialog box, click **Update**.

The **Active License** section of the **Licenses** page is updated.

## License a Virtual Edition

Virtual Edition licensing is handled through the RealPresence Platform Director system. In order to license your upgraded Virtual Edition previous to 8.2, you need to add it to the RealPresence Platform Director system.

For versions 8.2 and higher, you do not need to perform any additional steps to license your system after upgrading.

**For versions previous to 8.2:**

- From the RealPresence Platform Director system, add your RealPresence Resource Manager system, Virtual Edition instance to the RealPresence Platform Director system.

For complete instructions on how to use the RealPresence Platform Director system, Virtual edition, see the *RealPresence Platform Director System Administrator's Guide*.

## Upload Endpoint and Peripheral Software Updates

If your system had endpoint or peripheral software updates stored on it, you must upload those updates. They were not retained in the system backup.

If you stored them in another location in preparation for the upgrade, you can use that location as the source. If you did not, you can upload them from <http://support.polycom.com>.

For more information on these tasks, refer to the *Polycom Resource Manager System Operation Guide*.

## Verify the Upgrade

After completing the upgrade and verifying that you can access the system, you need to verify that your upgrade was successful.

### To verify that the upgrade was successful:

- 1 On the login screen, verify that the system displays the version number of software to which you are upgrading.
- 2 Verify that you can schedule and start a conference.
- 3 Verify that you can monitor a conference.
- 4 Verify that you can terminate a conference.
- 5 Review the CDR for the test conference and verify the record is accurate.

# Upgrading a Redundant Polycom RealPresence Resource Manager System

This chapter provides instructions for upgrading a redundant RealPresence Resource Manager system. See [Upgrading a Non-Redundant Polycom Resource Manager System](#) for instructions on upgrading a non-redundant system.

Give yourself plenty of time for the system upgrade process. It will take some time, depending on the environment. At some steps you are instructed to wait. **MAKE SURE YOU WAIT UNTIL THE PROCESS IS COMPLETE.** Interrupting the upgrade can corrupt the system.

During most of the upgrade process, the RealPresence Resource Manager system is offline and all services are unavailable. In addition, the serial console appears inactive; nevertheless, do not power off the system unless instructed to do so.

See the *Polycom RealPresence Resource Manager System Release Notes* for the version to which you are upgrading for information about valid upgrade paths.



## Upgrading a Virtual Edition

RealPresence Resource Manager system, Virtual Edition does not support redundancy. If you have a Virtual Edition, see [Prepare to Upgrade a Virtual Edition](#).

## About Redundancy and Upgrading a Redundant RealPresence Resource Manager System

A redundant RealPresence Resource Manager system configuration has two system servers and two IP addresses on the same network running in active/standby mode.

Take note of the following terminology:

- In a redundant configuration, one server is licensed as the *primary server* and the other server is licensed as the *redundant server*. That means that the primary server is always the primary server and the redundant server is always the redundant server.
- In a redundant configuration, there is only one *active server*. The active server is the server managing the system. That means when the redundant server is managing the system, it is the active server. This distinction is important when performing this upgrade.
- In a redundant configuration, there is only one *standby server*. The standby server is the server that is not managing the system. If at anytime you receive a **Cannot find server** error when you try to log into a server, check to see if it is the standby server.

Also note that in a properly configured and fully operational redundant configuration, you must log into the virtual IP address for the locally redundant system or the virtual FQDN for a geographically redundant system, unless you have troubleshooting needs. When you log into the web interface of RealPresence Resource Manager using the virtual IP address or the virtual FQDN, the **Redundant Configuration** page shows:

- A redundant system is fully operational when the redundant server is the active server and the primary server is the inactive server.
- Both servers have a **Machine Status** of ON.

When upgrading a redundant RealPresence Resource Manager system, you will be instructed when to disable redundancy between the primary and redundant servers and when to re-enable redundancy. During these procedure only one of the two RealPresence Resource Manager system servers is powered on at any given time. Be sure to follow these procedures carefully.

**To upgrade a redundant RealPresence Resource Manager system, complete the following tasks:**

- 1 [Request a Software License Upgrade File.](#)
- 2 [Download the Software Upgrade File.](#)
- 3 [Back Up the Redundant System.](#)
- 4 [Reset the Redundant System to be a Standalone Server](#)
- 5 [Back Up the Standalone System](#)
- 6 [Perform the Software Upgrade on Both Standalone Servers.](#)
- 7 [Reconfigure the Standalone Servers for Redundancy.](#)
- 8 [Verify the Upgrade](#)

## Request a Software License Upgrade File

You will need a software upgrade license file for the primary server in a redundant RealPresence Resource Manager system configuration.

**To request a software license file:**

- 1 In a separate browser page or tab, log into the RealPresence Resource Manager system server as an administrator using the virtual IP or virtual FQDN.
- 2 Navigate to **Admin > Server Settings > Licenses** and verify that the server type is Primary.  
If the server type is not primary. Perform a failover and repeat step 1.
- 3 Go to **Admin > Server Settings > Licenses** and record the RealPresence Resource Manager system server serial number.
- 4 Go to <http://support.polycom.com>.
- 5 In the **Licensing & Product Registration** section, select **Activation/Upgrade**.
- 6 Log in or **Register for an Account**.
- 7 Select **Site & Single Activation/Upgrade**.
- 8 In the **Site & Single Activation** page, enter the serial number you recorded.
- 9 Click **Next**.
- 10 Accept the **EXPORT RESTRICTION** agreement.
- 11 In the new **Site & Single Activation** page, enter the serial number listed on your License Certificate and enter the license number (shipped with the product) and click **Activate**.  
If retrieving licenses for a redundant system, repeat this step for each server in your configuration.
- 12 In the **Key Code** field, click **click here to download** to retrieve and save your license files.



## Download the Software Upgrade File

The software upgrade file is generally available on the Polycom support website.

### To download the software required to update the system:

- 1 On your local system, create a directory to which to save the software upgrade file if one does not already exist.
- 2 Using a web browser, go to <http://support.polycom.com>
- 3 In the **Documents and Downloads** section, select the appropriate **Category** (UC Infrastructure) and **Product** (RealPresence Resource Manager) for the required download and click **GO**.  
You'll be taken to the RealPresence Resource Manager system webpage.
- 4 Select the file for the version of software to which you are upgrading.
- 5 You'll be required to submit a confirmation that you have read the RealPresence Resource Manager system End User License Agreement (EULA).  
When the **File Download** dialog box appears, click **Save**.
- 6 When the **Save As** dialog box appears, browse to the directory created in step 1 and click **Save** to save the .bin file to your local system.
- 7 Record the location and name of the saved file.

## Back Up the Redundant System

You must back up the entire system. This process creates a backup archive of the RealPresence Resource Manager system.

For more information about backing up your system, see the chapter called “*System Backup and Recovery Operations*” in the *Polycom RealPresence Resource Manager System Operations Guide*.

### To backup the RealPresence Resource Manager system:

- 1 Log in to the RealPresence Resource Manager system *using the virtual IP address or the virtual FQDN*.
- 2 Navigate to **Admin > Dashboard** to view the **Redundancy Status** pane and verify that both servers are ON.
- 3 From the RealPresence Resource Manager system web interface, go to **Admin > Backup/Restore System Settings**.
- 4 When the **Backup/Restore System Settings** page appears, click **Create and Download a Backup Archive**.
- 5 When the system archive file has been created, you are asked if you want to continue. Click **Yes**.
- 6 Browse to a location on your system, enter a unique **File name**, and click **Save**.  
A **File Download** dialog box displays the progress of the download operation.
- 7 When the operation is completed, click **OK**.
- 8 Browse to the location specified in step 3 and verify the file download.

## Reset the Redundant System to be a Standalone Server

Use this procedure to discontinue redundancy, but only when the system is in a valid redundant state.

**To discontinue a redundant Polycom Resource Manager system configuration when the system is in a valid redundant state:**

- 1 Log into the system *using the virtual IP address or the virtual FQDN*.
- 2 Go to **Admin > Server Settings > Redundant Configuration**.
- 3 On the **Redundant Configuration** page, click **Reset Redundant Configuration**.  
The two servers restart as single servers.

## Back Up the Standalone System

You must back up the standalone system. This process creates a backup archive of the RealPresence Resource Manager system.

For more information about backing up your system, see the chapter called “*System Backup and Recovery Operations*” in the *Polycom RealPresence Resource Manager System Operations Guide*.

**To backup the RealPresence Resource Manager system:**

- 1 Log in to the RealPresence Resource Manager system.
- 2 From the RealPresence Resource Manager system web interface, go to **Admin > Backup/Restore System Settings**.
- 3 When the **Backup/Restore System Settings** page appears, click **Create and Download a Backup Archive**.
- 4 When the system archive file has been created, you are asked if you want to continue. Click **Yes**.
- 5 Browse to a location on your system, enter a unique **File name**, and click **Save**.  
A **File Download** dialog box displays the progress of the download operation.
- 6 When the operation is completed, click **OK**.
- 7 Browse to the location specified in step 3 and verify the file download.

## Perform the Software Upgrade on Both Standalone Servers

Perform these steps for each server in your redundant configuration.

Perform these steps on the primary server in your redundant configuration.



- The system upgrade process may take up to 90 minutes, depending on the environment. At some steps you are instructed to wait. **MAKE SURE YOU WAIT UNTIL THE PROCESS IS COMPLETE.** Interrupting the upgrade can corrupt the system.
- During the upgrade, the RealPresence Resource Manager system is offline and all services are unavailable. Do not power off the system unless instructed to do so.
- You must access the RealPresence Resource Manager system through Microsoft Internet Explorer in order to perform an upgrade.

### To upgrade the RealPresence Resource Manager software:

- 1 Go to **Reports > System Log Files** and verify that the **Current Log Level** is set to **Info**.
- 2 Go to **Admin > Maintenance > Server Software Upgrade**.
- 3 From the **Server Software Upgrade** page, click **Upload upgrade file to server** and browse to the location of the upgrade file saved in [Download the Software Upgrade File](#) on page 9.
- 4 Select the **.bin** file and click **Open**.  
The **.bin** file uploads to the system.



#### **Browser Requirements for File Uploads**

You must access the RealPresence Resource Manager system through Microsoft Internet Explorer in order to perform an upgrade.

**DO NOT** close the upload page while the upgrade is taking place.

- 5 When the system indicates the **File Upload** is **Complete**, click **OK**.
- 6 Click **Upgrade**.  
When the status messages on the upgrade screen start changing ("Stopping services", "applying upgrade", etc.), the upgrade process has started. When the upgrade process is complete, the system reboots.  
**DO NOT** close the browser while the upgrade is taking place.
- 7 When the upgrade is finished, a dialog displays the following message, **Upgrade Completed**. **Click to Log In**. You can now log back into the system.

## Reconfigure the Standalone Servers for Redundancy

For detailed instructions on how to configure RealPresence Resource Manager for redundancy, see the "System Redundancy" chapter of the *Polycom RealPresence Resource Manager System Operations Guide*.

## Upload the New License File

This topic describes how to upgrade a licensed redundant system. You only need to upload one upgrade license file.

### To license a redundant system:

- 1 Log into the RealPresence Resource Manager system *using the virtual IP address or the virtual FQDN*, and go to **Admin > Server Settings > Licenses**.
- 2 Click **Update License**.
- 3 Follow the instructions on the **Update License** dialog and be sure you have a backup copy of your initial license file.
- 4 Click **Choose File** and navigate to the primary license file you requested.
- 5 Click **Preview** to preview the license features and then click **Apply**.
- 6 Click **Update License** again.

## Verify the Upgrade

After upgrading your system, you should verify that it was successful.

### To verify that the upgrade was successful:

- 1 On the login screen, verify that the system displays the version number of software to which you are upgrading.
- 2 Verify that you can schedule and start a conference.
- 3 Verify that you can monitor a conference.
- 4 Verify that you can terminate a conference.
- 5 Review the CDR for the test conference and verify the record is accurate.