



RELEASE NOTES

6.0.1 | January 2017 | 3725-63711-035C

Polycom[®] RealPresence[®] Group Series

Contents

- [Overview](#)
- [RealPresence Group Series Product Family](#)
- [RealPresence Group System Bundles](#)
- [System Performance](#)
- [Language Support](#)
- [Monitor Setup](#)
- [System Configuration and Setup](#)
- [Polycom Labs Experimental Features](#)
- [Install the Software](#)
- [Software Version History](#)
- [New Features in Version 6.0.1](#)
- [Polycom Solution Support](#)
- [Hardware and Software Compatibility](#)
- [Security Updates](#)
- [Resolved Issues in Version 6.0.1](#)
- [Known Issues in Version 6.0.1](#)
- [Hardware and Software Requirements](#)
- [Interoperability](#)
- [Copyright Information](#)

Overview

Polycom announces a new release of Polycom® RealPresence® Group Series software. This document provides the latest information about the following Polycom software:

- Version 6.0.1 of the Polycom RealPresence Group system software
- Version 2.2 of the Polycom® EagleEye™ Director software
- Version 1.2 of the Polycom EagleEye Producer software
- Version 6.0.1 of the Polycom® RealPresence Touch™ Panel software
- Version 2.0.0 of the Polycom RealPresence Touch Operating system software
- Version 6.0.1 of the Polycom® Touch Control™ Panel software
- Version 6.0.1 of the Polycom Touch Control Operating System software



Note: The RealPresence Touch Panel software is included in the RealPresence Group Series system software package. The RealPresence Touch Operating system software is available for download at support.polycom.com.

RealPresence Group Series Product Family

The RealPresence Group Series product family includes a codec, plus a remote control, cameras, microphone arrays, and other supported accessories. A comprehensive list of available accessories is available at www.polycom.com.

Codec Power Options

The RealPresence Group 300, RealPresence Group 310, and the RealPresence Group 500 systems have an external power transformer. The RealPresence Group 700 system has an internal power supply.

Codec Mounting Options

The RealPresence Group 300, RealPresence Group 310, and the RealPresence Group 500 systems have options for rack shelf mounting, or a 'bunk bed' for co-mounting with the EagleEye cameras using their mounting options. The RealPresence Group 700 system can be rack mounted with rack ears that are included with the codec.

Remote Control Devices

The RealPresence Group system remote control device is included with all RealPresence Group Series bundles and includes a USB rechargeable lithium-Ion battery. Additional USB lithium-Ion batteries are available. Remote control devices for earlier Polycom systems, such as Polycom® HDX® system remotes, are also supported.

Digital and Analog Cameras

The supported EagleEye digital output cameras include the EagleEye Acoustic, EagleEye Producer, EagleEye IV-4x and the EagleEye IV-12x. An optional wide angle lens for the EagleEye IV camera increases the FOV from 65 degrees to 85 degrees.

The RealPresence Group Series systems also support the EagleEye analog output cameras, which include the EagleEye View, EagleEye HD, EagleEye II, and EagleEye III cameras.

Camera Mounts and Accessories

Accessories for the digital cameras include the EagleEye Digital Extender and the Digital Breakout Adapter. Additional digital cables for the EagleEye IV of 300mm, 457mm, 10m, and 1m length are available. The Universal Mounting shelf was designed for use with the EagleEye IV cameras and support mounting on a monitor, wall and tripod.

The RealPresence Group Series systems also support the EagleEye Director and the EagleEye Producer camera accessories. The EagleEye Producer has an optional mounting bracket for use with the universal camera mounting solution.

Audio Accessories

The following audio accessories are supported on the RealPresence Group Series codecs: RealPresence Group Series microphone array, SoundStation IP 7000 integration, SoundStructure integration, the HDX microphone array, and the ceiling microphone arrays.

More Interoperable Hardware and Accessory Options

Other accessories and hardware available for the RealPresence Group Series includes the Polycom® UC Board™, Polycom RealPresence Touch, Polycom Touch Control, and a transport case. Replacement power supplies are available for RealPresence Group 300, 310, or 500 systems. In addition, a full line of RealPresence Group Media Centers are available with options from 27" to 84" displays and tabletop, stand, and wall mounting.


RealPresence Group System Bundles

Depending upon which RealPresence Group system that you purchase, a bundle of accessories is shipped with the system.

RealPresence Group 300 and 310 Systems

RealPresence Group 300 and 310 systems ship with either an EagleEye Acoustic or Polycom® EagleEye™ IV camera, a RealPresence Group Remote Control, and a RealPresence Group Microphone Array.


RealPresence Group 300 and 310 system and accessories



RealPresence Group 500 Systems

RealPresence Group 500 systems ship with either an EagleEye Acoustic or a Polycom® EagleEye™ IV camera, a RealPresence Group Remote Control, and a RealPresence Group Microphone Array.

RealPresence Group 500 systems and accessories



RealPresence Group 700 Systems

RealPresence Group 700 systems ship with a Polycom EagleEye IV camera, a RealPresence Group Microphone Array, a RealPresence Group Remote Control and rack mounting ears.

RealPresence Group 700 system and accessories



System Performance

The RealPresence Group systems are cutting-edge visual collaboration tools that provide high quality video, audio, and data collaboration. The systems use the most up-to-date video communications technology to deliver the most natural video conferencing experience.

The RealPresence Group systems support up to 1080p60 performance for people and content, for a new level of clarity and realism. RealPresence Group 300, RealPresence Group 310, RealPresence Group 500 systems support 1080p60 performance for either people or for content. RealPresence Group 700 systems support 1080p60 performance for people and content at the same time. You can pair all of the systems with the Polycom® EagleEye Director™, EagleEye Producer, RealPresence Touch, or Polycom Touch Control to turn them into even more powerful room-based video systems.

Language Support

The RealPresence Group Series web and local user interfaces provide support for the following languages:

- Arabic
- Chinese (Simplified)
- Chinese (Traditional)
- British English
- American English
- French
- German
- Hungarian
- Italian
- Japanese
- Korean
- Norwegian
- Polish
- Portuguese (Brazilian)
- Russian
- Spanish

Monitor Setup

Depending on the monitor you are using with the RealPresence Group system, you might want to change some default settings. Before setting up your system, review the following information to determine what changes might be necessary.



Note: When the USB interface is connected to a RealPresence Group Series system, a touch option appears on your touch monitor. If the USB interface is either disconnected or switched away from the Polycom RealPresence Group Series system, then the system will reconfigure automatically to not use the touch capability. This assures that the system is always available to a user.

Display All Pixels

Before attaching your RealPresence Group system to a TV monitor, ensure the monitor is configured to display all available pixels. This setting, also known as *fit to screen* or *dot by dot*, enables the entire HD image to be displayed. The specific name of the monitor setting varies by manufacturer.

Ensure Monitor Availability

By default, the RealPresence Group system sends no signal when it goes to sleep. This might result in some monitors turning off or entering standby mode. If your monitor does not wake up when the RealPresence Group system wakes up and reestablishes the signal, you have several options:

- Turn the monitor off and on again before using the RealPresence Group system.
- Configure the monitor to enter standby mode when it is not receiving a signal.
- Set up the RealPresence Group system to display black video when it goes to sleep, instead of not sending a signal.

HDCP Content Sources

The High-bandwidth Digital Content Protection (HDCP) standard does not support the use of HDCP by a videoconferencing system. If you connect a content source that sends HDCP-encrypted content, the content displays as black video on the near and far-end sites. To ensure that content displays correctly, send content in a format other than HDCP.

HDCP on Apple Computers

Due to a policy established by Apple Computer, Inc., you cannot disable the HDCP encryption service on the DVI or HDMI outputs of a computer that is manufactured by Apple Computer, Inc.

Multipoint Layouts and System Type

When the host of a conference call is a RealPresence Group 500 system, the system displays all remote sites on a split screen with the speaker in a large window. On the RealPresence Group 700 system, up to eight sites display on the monitor based upon layout chosen. When the host has dual monitors, the layout can span both monitors. The far-end site sees four sites, with each quadrant displaying the last four speakers.

System Configuration and Setup

Administrator settings are available to configure in the system's web interface. Calling functions for users are available in the local interface.

For more information about setting up and using the RealPresence Group systems, refer to the documents on the product pages at support.polycom.com.



Note: Every time you power on a RealPresence Group system, a splash screen appears on the monitor with a note to wait as the system starts. The monitor then goes black for a period of time. Do not attempt to turn off or restart the system during this time.

Update to Account IDs

The text string `root` is no longer allowed when configuring the ID for the administrator or user account on a RealPresence Group Series system. Attempting to set either account to any variance of `root` will result in an error.

If you upgrade to RealPresence Group Series 6.0.1 or higher on a system that is running software version 6.0.0 or earlier and the value of an account ID is set to any variance of `root`, the following modifications will be made automatically during the upgrade process:

- The Admin ID will be changed to the default Admin ID: `admin`.
- The User ID will be changed to the default User ID: `user`.

The existing password is not modified.

Polycom Labs Experimental Features

You can now enable experimental features and evaluate them in a non-production environment. For more information about the experimental features or to provide feedback on your experience, visit the [Polycom Support Community](#).



Note: Experimental features are neither tested nor supported. These features might, or might not, become official features in a future release.

To enable the experimental features:

- 1 In the web interface, select **Admin Settings > General Settings > System Settings > Polycom Labs**.
- 2 Select the **Enable Polycom Labs Features** checkbox to enable all experimental features.

These are the experimental features in this release:

[VisualBoard Advanced Features](#)

[Incoming NoiseBlock](#)

[Acoustic Fence with Beam Shaping](#)

[Auto Wakeup Feature for Polycom EagleEye Producer](#)

[Content Stretch](#)

[Dual Live-Stream](#)

VisualBoard Advanced Features

- **Enable PowerPoint Slide Conversion:** Show PowerPoint document files while working in VisualBoard.
- **Allow Slide Zoom:** Enlarge a slide by moving two fingers in opposite directions while in drawing mode.
- **Allow Swipe Navigation:** Move to the next slide by swiping, or fast dragging, while in pointer mode.

Incoming NoiseBlock

When the Incoming NoiseBlock feature is enabled, the RealPresence Group system automatically senses ambient noise in the far-end audio and mutes the loudspeaker. Ambient noise can include keyboard typing, paper shuffling, or any sounds other than human speech. As soon as the far-end meeting participant begins speaking, the system automatically unmutes the loudspeaker.



Note: If a RealPresence Group 500 or 310 system has Incoming NoiseBlock enabled and a computer is connected to its HDMI input port as its content source, the audio from the HDMI input may fade in and out at the local end.

Acoustic Fence with Beam Shaping

Acoustic Beam greatly reduces sounds outside a well-defined beam. The beam width can vary from +/- 10 degrees to +/- 60 degrees. A single tabletop microphone, a single ceiling ball, or a single EagleEye Acoustic camera forms the beam by appropriate signal processing on the microphones contained in the unit.

If two tabletop microphones or two ceiling balls are connected to the system, only sounds inside the intersection of the beams formed by each of the two tabletop microphones or two ceiling balls is picked up. In addition, you can connect one tabletop microphone and one ceiling ball, and only sounds within the intersection of their two beams is picked up.

Try using two desktop microphone arrays to define a region of audio pickup through the beam intersection. It will take some experimentation to find the optimal rotation angle and position of each array to create the desired audio pickup region.



Note: The Acoustic Fence with Beam Shaping and Acoustic Fence Technology features cannot be enabled at the same time. To disable Acoustic Fence, in the web interface, go to **Admin Settings > Audio/Video > Audio > General Audio Settings**. Clear the **Enable Acoustic Fence** checkbox.

In this release, the Acoustic Fence with Beam Shaping feature has been updated to include a new Beam Mode: **automatic steering beam**. This setting automatically steers the beam to the meeting participant who is talking. This setting is the default. You can also set Beam Mode to **fixed beam**.

To use the Acoustic Fence with Beam Shaping feature, you must enable it in the web interface.

To enable and configure Acoustic Fence with Beam Shaping:

- 1 In the web interface, go to **Admin Settings > General Settings > System Settings > Polycom Labs** and select the checkbox at **Enable Polycom Labs Features**.
- 2 Under the **Acoustic Fence with Beam Shaping** category, select **Enable Acoustic Fence with Beam Shaping**.
- 3 Select a **Beam Mode** and save your settings.

Auto Wakeup Feature for Polycom EagleEye Producer

This feature enables an EagleEye Producer to automatically wake up when it detects the presence of people or faces.

Content Stretch

This feature allows RealPresence Group systems to stretch the content to fit the monitor. When this feature is enabled, content is shown full screen without the black bars even though the receiving content aspect ratio might not be 16:9.

Dual Live-Stream

This feature adds the ability to combine two cameras as a single camera source. The encoded stream to be sent to the far site consists of a single stream of encoded video that will include two camera views. The far end will notice two camera views from the far site. They will not notice a difference in call connection, negotiation, or quality. This feature is only supported on RealPresence Group 700 systems.

The following layouts are supported:

- Equal size
- Main camera only
- Room camera only
- Main camera in PIP
- Room camera in PIP
- Side by side 3D
- Top and bottom 3D

Install the Software

Procedures for installing and updating RealPresence Group system software vary. With your license key, you can update directly from software version 4.0.2 or higher to 6.0.1.

When updating the system software to version 4.1.x or later, make sure you are currently running version 4.0.2 or later.

- If you are running version 4.0.0, 4.0.0.1, or 4.0.1, download and install version 4.0.2 from support.polycom.com before you download and install a 4.1.x version.
- If you are already running version 4.0.2 or later, you can follow the procedures described in *Polycom RealPresence Group Series Administrator Guide* at support.polycom.com.

Software Version History

RealPresence Group System Software

Software Version	Release Date	Description
6.0.1	November 2016	Includes escalation fixes and documentation updates. Provides support for EagleEye Producer software 1.2.1.
6.0.0	September 2016	Includes new Skype for Business and Microsoft Office 365 features; provides integration of Polycom RealPresence Media Suite recording controls; adds Polycom RealPresence Cloud service interoperability and new EagleEye Producer tracking modes; provides support for MusicMode on the G.719 codec, audio-only calls, custom backgrounds, USB headsets, additional multipoint layout views on RealPresence Group 700 systems, and Polycom SoundStructure system control using the RealPresence Touch device; provides enhanced DTMF dialing and updates to persistent video layout views; includes updates to the API and documentation.
5.1.2	June 2016	Includes escalation fixes for customer support.
5.1.1	May 2016	Includes support for the Polycom Concierge solution, 4-Way Symmetric 1080p in Full Screen Mode, API command audio3p5inputfaronly, and escalation fixes for customer support.
5.1.0	February 2016	Includes escalation fixes and support for the touch-enabled user interface, and updates the factory partition to version 5.1.0.
5.0.2	January 2016	Includes escalation fixes and documentation updates.
5.0.1	November 2015	Includes escalation fixes and documentation updates. Provides support for EagleEye Producer software 1.1.1.
5.0.0	September 2015	Includes support for Microsoft Office 365 calendaring, first release of the RealPresence Touch device, adds support for viewing content from Microsoft Lync desktop clients, add provisioning capabilities, includes enhancements to security for SIP applications, adds support for Lync Response Group registrations, adds Native Support for RealConnect feature, support for Link Layer Discovery Protocol (LLDP) and Link Layer Discovery Protocol Media Endpoint Discovery (LLDP/MED), new API commands, adds improvements to import and directory interface, support for new EagleEye IV mounting option, includes Acoustic Fence technology, includes update to web interface to include 3.5mm audio input, includes support for EagleEye Producer software 1.1 that has automatic camera updates, and includes support for several experimental features.
4.3.2	August 2015	Includes escalation fixes and documentation updates.
4.3.1	June 2015	Provides support for EagleEye Producer software 1.0.1.17, and corrected issues from the previous RealPresence Group Series release.

Polycom RealPresence Group Series Release Notes

Software Version	Release Date	Description
4.3.0	May 2015	Includes support for the RealPresence Group Series 310 system, using SSH for secure API access, enabling and disabling Audio Add In, and Polycom EagleEye Producer version 1.0.0.
4.3.0	March 2015	Includes support for using SSH for secure API access, enabling and disabling Audio Add In, and Polycom EagleEye Producer version 1.0.0.
4.2.0	January 2015	Includes support for additional Microsoft Lync 2013 enhancements; adds CEC monitor controls; includes SVC updates; adds support for enhanced High Definition video resolution; includes updates to receiving software updates from the web interface, and adds accessible HTML help; adds support for a visual security classification feature; includes support for People+Content IP 1.3; provides updates to the API; includes support for Polycom EagleEye Producer.
4.1.3.2	April 2014	Correction for the Heartbleed OpenSSL Security Vulnerability in third-party software.
4.1.3	February 2014	Provides native Microsoft Lync 2013 interoperability; adds support for recording on RealPresence Group 700 systems; includes more robust and secure SNMP and system logging functionality; adds support for BroadSoft BroadWorks DMS provisioning; provides support for the Polycom VisualBoard application; includes updates of SVC functionality; includes support for a new version of the Polycom EagleEye Director which has a new tracking mode; provides updates to the API.
4.1.1.1	September 2013	Includes support for additional Lync 2013 enhancements; adds Cisco TIP interoperability; replaces version 4.1.1.
4.1.1	July 2013	Provides enhanced security; includes Scalable Video Codec (SVC) updates; adds compatibility for Microsoft Lync 2013; provides remote management of the Polycom Touch Control; supports Polycom Calendering for Microsoft Outlook.
4.0.2	March 2013	Added support for the SVC protocol and RealPresence Group 700 system; enabled Monitor Profiles for configuring viewing and recording preferences.
4.0.1	January 2013	Enabled Polycom® SmartPairing™ in automatic mode with the RealPresence Mobile application on an Apple iPad; added more diagnostic features; included API support for a broadcast beacon to an AMX® NetLinx™ central controller; added support for software downgrade via USB; added support for the EagleEye Acoustic camera; updated EagleEye Director software to version 2.1, which adds camera support for 1080p with 60 frames per second.
4.0.0.1	November 2012	Correction for an issue recently observed at the factory in which RealPresence Group systems restarted intermittently while in a call; replaces 4.0.0.
4.0.0	November 2012	First release of software to support the RealPresence Group 300 and 500 systems.

New Features in Version 6.0.1

RealPresence Group Series system software version 6.0.1 provides the functionality described in the following sections:

- [Content Sharing Out of Call in Skype For Business Environment](#)
- [Maximum Ventilation Option](#)

Content Sharing Out of Call in Skype For Business Environment

The Content Sharing Out of Call in Skype For Business Environment provides Polycom RealPresence Group Series support for content sharing from Microsoft Lync/Skype for Business clients. This protocol (RDP) does not require the Polycom RealPresence Group Series system to be in an audio/video call.

Maximum Ventilation Option

The Maximum Ventilation Option reduces thermal stress to the power supply by increasing the fan speed from 35% to 80%. This is useful when the system is used in higher thermal areas such as enclosures with limited ventilation, 24/7 operations, hosting multipoint calls and sharing content.

By default the option is checked **On** resulting in the increase of the fan speed up to 80%. The fan runs at a lower speed (35%), thus reducing the fan speed and increasing thermal stress on the power supply, when the option is un-checked.

The Maximum Ventilation Option is applicable for the Polycom RealPresence Group Series 700 system only and hardware lower than version 20.



The Maximum Ventilation Option is not available on Polycom RealPresence Group Series 300 or 500 systems and on Polycom RealPresence Group 700 systems with a hardware version higher than or equal to 20.

To set the Maximum Ventilation Option:

In the web user interface, go to **Diagnostics > System > System Log Settings > Maximum Ventilation Option**.

Polycom Solution Support

Polycom Implementation and Maintenance services provide support for Polycom solution components only. Additional services for supported third-party Unified Communications (UC) environments integrated with Polycom solutions are available from Polycom Global Services, and its certified Partners, to help customers successfully design, deploy, optimize, and manage Polycom visual communication within their third-party UC environments. UC Professional Services for Microsoft® Integration is mandatory for Polycom Conferencing for Microsoft Outlook and Microsoft Office Communications Server or Microsoft Lync™ Server integrations.

For additional information and details, refer to professional_services/index.html or contact your local Polycom representative.

Hardware and Software Compatibility

The following table lists RealPresence Group system software versions that are compatible with RealPresence Group system hardware.



Note: Polycom recommends that you upgrade all of your Polycom systems with the latest software versions. Any compatibility issues may already have been addressed by software updates. Go to PolycomService/support/us/support/service_policies.html to see the Current Polycom Interoperability Matrix.

Hardware Model	Part Number (or Serial Number)	Designation in User Interfaces	Compatible Software Versions
RealPresence Group 700	2201-08090-xxx	Hardware version 7 Hardware version 8	4.1.3 and higher 4.1.3 and higher
RealPresence Group 700	2201-09770-xxx	Hardware version 6 Hardware version 7	4.0.2 and higher 4.1.3 and higher
RealPresence Group 500	2201-68113-xxx	Hardware version 16 Hardware version 18	4.2.0 and higher 4.2.0 and higher
RealPresence Group 500	2201-09790-xxx	Hardware version 9 Hardware version 10 Hardware version 12 Hardware version 15 Hardware Version 17	4.0.0 and higher 4.1.3 and higher 4.1.3 and higher 4.1.3 and higher 4.2.0 and higher
RealPresence Group 310	2201-68113-xxx	Hardware version 16 Hardware version 18	4.3.0 and higher 4.3.0 and higher
RealPresence Group 300	2201-68108-xxx	Hardware version 16 Hardware version 18	4.2.0 and higher 4.2.0 and higher
RealPresence Group 300	2201-64752-xxx	Hardware version 9 Hardware version 10 Hardware version 12 Hardware version 15 Hardware Version 17	4.0.0 and higher 4.1.3 and higher 4.1.3 and higher 4.1.3 and higher 4.2.0 and higher

Supported Operating Systems, Web Browsers, and Peripherals

The RealPresence Group system web interface requires Windows® Internet Explorer 10 or 11 on Windows 8, Apple® Safari® 9.0.3 on Mac OS® X (Yosemite), or Mozilla Firefox 44 on Windows 8.

RealPresence Group systems support the following components:

- Polycom EagleEye Producer
- Polycom EagleEye Director
- Polycom RealPresence Touch
- Polycom Touch Control
- Polycom EagleEye Acoustic, EagleEye III, EagleEye II, EagleEye 1080, EagleEye View, EagleEye HD, and EagleEye IV cameras
- Polycom RealPresence Group Microphone Array
- Polycom® HDX® system table microphone arrays and ceiling microphone arrays
- Polycom® SoundStructure®
- Polycom Stereo Speaker Kit
- Polycom® SoundStation® IP 7000 phone

For specific version support information, see Products Tested in this Release.

Supported Touch-Capable Monitors

The touch-enabled user interface and VisualBoard are compatible with the following touch-capable monitors.

Brand	Model	Size
Acer	T232HL	23"
Acer	T272HL	27"
HP Compaq	L2206tm	22"
LG	LG KT-T430 overlay on LG-43SL5B LG-43SE3B	43"
LG	LG KT-T490 overlay on LG-49SL5B LG-49SE3B	49"
LG	LG KT-T550 overlay on LG 55SL5B LG-55SE3B	55"
LG	LG KT-T650 overlay on LG 65LS33A	65"
NEC	V552TM	55"
Orion	Orion OLS-7010T6	70"

Brand	Model	Size
Planar	PCT2785	27"
Sharp	PN-L702B PN-L703B	70"

Security Updates

For information about known and resolved security vulnerabilities, refer to the [Polycom Security Center](#).

Resolved Issues in Version 6.0.1

The following table lists issues resolved in version 6.0.1

Category	Key	Description
Calling	GS-28763	The Japanese Translation for Switch To option appearing in Skype for Business call is not required. This issue has been resolved.
Calling	GS-32574	Calling from the RealPresence OTX Studio 6.0 to RealPresence OTX Studio 5.1.2 results in local audio feedback. This issue has been resolved.
Cameras	GS-32301	In an ongoing peer to peer call, the EagleEye Director does not go to the established shot when there is no active audio on the SUT. This issue has been resolved.
Cameras	GS-31427	In the RealPresence OTX Studio, the Web UI images from the left, center and right camera remains blue. This issue has been resolved.
Cameras	GS-31091	The Polycom RealPresence Group Series 700 system is unable to switch from camera 2 to camera 1 using RealPresence Touch device. This issue has been resolved.
Cameras	GS-32568	When an EagleEye Producer hardware version E camera with an EagleEye IV camera is connected to a RealPresence Group system and when the cameras and the system are in sleep mode for less than five seconds, sometimes the EagleEye Producer camera does not wake up. This issue has been resolved.
Monitors	GS-30233	The Place a Call screen button fails to respond on a Polycom RealPresence Group Series with dual touch monitors. This issue has been resolved.
Monitors	GS-30121	Sometimes, the Sharp LC90-KE657U 90" LED display (through CEC) fails to wake up when connected to Polycom RealPresence Group Series 500 system. This issue has been resolved.
Network	GS-31309	The Polycom RealPresence Group Series endpoints fail to provide the network usage data to Polycom RealPresence Media Application. This issue has been resolved.

Category	Key	Description
Power	GS-32408	The Polycom RealPresence Group Series 700 system fails to start due to power supply failure. This issue has been resolved.
Video	GS-31937	In an H.323 call, when the Polycom RealPresence Group Series 500 system sends content to the LifeSize Room 220, the RealPresence Group Series 500 system experiences heavy packet loss on the video. This issue has been resolved.

Known Issues in Version 6.0.1

The following table lists the known issues for the version 6.0.1 release. If a workaround is available, it is noted in the table.

Category	Issue ID	Description	Workaround
API	GS-25980	The API calendarmeetings command might not send notifications.	
Calling	GS-9293	When placing calls through an ISDN gateway, the system cannot dial line rates that are multiples of 56 kbps. RealPresence Group systems only support call rates that are multiples of 64 kbps.	
Calling	GS-13144	If the call rate is high when placing a call to a remote endpoint through a FW/NAT device, the video might become degraded due to reduced video rate.	
Calling	GS-16896	If a RealPresence Group system is in an SVC conference and the downlink bandwidth is 256k or less, the SVC call might be disconnected after a few minutes.	
Calling	GS-24637	If two RealPresence Group systems are registered with OpenScape Video (OSV), and encrypted calls are made through the UNIFY session border controller (SBC), calls might sometimes connect over audio.	
Cameras	GS-7098	When a RealPresence Group system is not in a call, the Mute button cannot be used to enable or disable EagleEye Director tracking.	Enable or disable camera tracking from the Menu screen in the local interface.

Category	Issue ID	Description	Workaround
Cameras	GS-8418	When changing the Country setting from a PAL to NTSC country, or vice versa, on a RealPresence Group system that is attached to an EagleEye 1080 camera, the system must be restarted before the change takes effect on the camera.	
Cameras	GS-9822	If you replace one of the cameras in the EagleEye Director automatic camera positioning system while it is in use, the RealPresence Group system might not be able to detect the EagleEye Director.	Power off the EagleEye Director, then power it back on and ensure that the RealPresence Group system properly detects the EagleEye Director.
Cameras	GS-12308	If the name of a camera connected to a RealPresence Group system is longer than 32 characters, the following error message displays in the web interface: One or more errors occurred. Please try again.	Make sure the camera name is no longer than 32 characters.
Cameras	GS-17535	If a RealPresence Group system is running a software version earlier than 4.1.3 and is connected to an EagleEye IV camera, the system might continuously restart.	Before connecting an EagleEye IV camera, update the RealPresence Group system to version 4.1.3 or later.
Cameras	GS-25946	RealPresence OTX Studio only: After you calibrate the cameras, each camera will independently adjust based on objects in the camera's field of view.	Refer to the OTX Studio Installation Guide for more information.
Cameras	GS-30625	The PTZ camera control functions for the Near-End Loop diagnostic test no longer work.	
Cameras	EEP-381	Calibrating the EagleEye Producer internal camera using remote control results in video latency.	Wait for few seconds, the video will resume to normal state.
Cameras	VHD-1509	On rare occasions, an EagleEye IV camera or EagleEye Acoustic camera connected to a RealPresence Group 310 or 500 system with hardware version 18 and above will not display video when booting up.	Power off the RealPresence Group system and then power it back on.
Content	GS-9043	Sharing content on a RealPresence Group system by using a 1280 x 1024 resolution with a 85 Hz refresh rate is not supported.	Use a refresh rate of 60 Hz or 75 Hz.

Category	Issue ID	Description	Workaround
Content	GS-10151	The RealPresence Group series does not support HDCP (high-bandwidth digital content protection). If you connect a content source that sends HDCP-encrypted content, the content is not shown (on the local or far side) and the screen displays black video.	When sending content, do not use a content source using HDCP. See the note about HDCP earlier in this document.
Content	GS-15020	When a RealPresence Group Series system is configured with TIP enabled and joins a TIP-aware RealPresence Collaboration Server conference, content sent from the RealPresence Group system is played on the People channel.	On the web interface, go to Admin Settings > Network > Dialing Preference > Dialing Option and disable the TIP setting.
Content	GS-15320	On a RealPresence Group 700 system, VGA content might take a few seconds to start. During this time, the system might intermittently display Sending Content. When the content begins, the resolution might be incorrect.	
Content	GS-23968	In an RMX call, if you switch content from People+Content IP to VisualBoard, content might not launch on the first try.	Relaunch VisualBoard to show content.
Content	GS-24508	RealPresence Group systems do not support reloading shared content when a VMR call with multiple participants is placed on hold and then resumed.	
Content	GS-28276	When a RealPresence Group system shares content in a long duration, multi-point call, the content may be sent over the people channel instead of the video channel.	Hang up the call, re-establish the connection, and restart the content.
Content	GS-31807	Sending content from a RealPresence Debut system to a RealPresence Group system with BFCP set to TCP may fail if the RealPresence Debut system initiates the call.	Initiate the call from the RealPresence Group system.
Content	GS-32296	In a multipoint call hosted by a RealPresence Group Series codec while sharing content, the Call Statistics screen may take up to 20-second to refresh.	
Content	GS-32659	Sometimes, the RDP content is presented in PIP layout mode instead of full screen mode on monitor-1 when monitor-2 is turned off.	

Polycom RealPresence Group Series Release Notes

Category	Issue ID	Description	Workaround
Content	GS-32662	On the Polycom RealPresence Group Series 500 system, the monitor-1 displays RDP content based on the monitor profile is set when detected. However, monitor-2 displays RDP content even though the monitor profile is not set to receive content when detected.	
Directory	GS-20379	Directory entries imported from RealPresence HDX systems to RealPresence Group systems using the Directory Import/Export feature do not maintain the RealPresence HDX Directory grouping structure.	
Directory	GS-25910	The focus may disappear when you add a contact to favorites by searching the directory on the local interface.	
Gatekeepers	GS-11469	Polycom RealPresence Group systems cannot be configured to use Avaya gatekeepers.	
Hardware	GS-22016	Factory restore might not work correctly when you unplug the power cord, press the factory restore button, and plug the power cable back in.	For the correct factory restore procedure, refer to the <i>Polycom RealPresence Group Series Administrator Guide</i> .
Interop Broadsoft	GS-24812	When a RealPresence Group system is registered to Broadsoft BroadWorks using Sonus SBC with the TLS transport protocol, and a call is made from the RealPresence Group system to a RealPresence Distributed Media Application (DMA) VMR, the call might disconnect if after 30 minutes into the call the call is placed on hold.	
Interop Cisco	GS-21507	When Immersive Studio systems, registered to CUCM, are in a point-to-point SIP call, call statistics show the call connecting at lower than set preferred speeds and do not match between SUT and EP1.	Register to Polycom DMA trunked to CUCM.
Interop Cisco	GS-21963	When a RealPresence Group 500 or 550 system is in an encrypted SIP call registered over TLS to a Cisco VCS, and the system places a SIP call to a RealPresence Group 700 system, the RealPresence Group 700 system may not receive video from the RealPresence Group 500 or 550 system.	On the web interface of the RealPresence Group 500 or 550 system, go to Admin Settings > Network > IP Network > SIP and enable the Force Connection Reuse setting.

Category	Issue ID	Description	Workaround
Interop Cisco	GS-24645	When a RealPresence Group system connects to a Cisco C-Series system in a H.323 encrypted conference call, loud screeching audio may be heard when the Cisco C-series encryption KeySize is set to Min1024bit.	On the Cisco C-series system, set Encryption KeySize to Max1024bit (the default).
Interop LifeSize	GS-12496	If a LifeSize Team 220 system is the first system called in a SIP conference call, video is not received from the LifeSize system.	Either do not dial the LifeSize system first, or dial the system at a very low call rate, such as 384 kbps.
Interop LifeSize	GS-13316	A call between a RealPresence Group system and a LifeSize desktop client that uses an unregistered IP address might not have video.	Register both systems to a SIP proxy.
Interop LifeSize	GS-20717	When a RealPresence Group system is in a multipoint call with a LifeSize ICON 600 endpoint using SIP protocol at a 1920k rate, the RealPresence Group system does not receive content.	
Interop Microsoft	GS-12982	When a RealPresence Group system is in a multipoint call hosted by a Microsoft Lync AV MCU, the RealPresence Group system participant name, number, and system values on the Settings > System Information > Call Statistics screen might be incorrect.	
Interop Microsoft	GS-16065	When recording is paused on a Lync 2013 client, the red recording icon still displays in the local interface.	
Interop Microsoft	GS-18630	RealPresence Group systems currently do not support Lync mobility clients.	
Interop Microsoft	GS-21208	A RealPresence Group system cannot join a consultative transfer from the Lync Client 2013.	
Interop Microsoft	GS-21207	Blind transfers from an internal RealPresence Group Series system to a federated external RealPresence Group Series system over Lync Attendant Console do not work.	
Interop Microsoft	GS-21088	RealPresence Group systems do not register with the SIP protocol to the backup Lync server in failover tests.	

Polycom RealPresence Group Series Release Notes

Category	Issue ID	Description	Workaround
Interop Microsoft	GS-20919	RealPresence Group Series endpoints might take more than 30 seconds to connect to a federated Lync online meeting that requires media over TCP.	
Interop Microsoft	GS-21450	When a RealPresence Group Series system becomes the active speaker in conference calls with a Lync client and an HDX system, the RealPresence Group Series system video delays and freezes on the HDX.	
Interop Microsoft	GS-23632	If the presenter in a MeetNow call mutes the conference and the RealPresence Group system participant tries to unmute, the RealPresence Group system participant will not receive a notification that they cannot unmute the call.	Request the presenter unmute the call.
Interop Microsoft	GS-24545	RealPresence Group systems do not display scroll bars when scrolling through Microsoft Lync or Skype for Business content.	
Interop Microsoft	GS-26430	The RealPresence Group system does not register with the SIP protocol to the backup Lync server in failover tests.	
Interop Polycom SoundStation IP 7000	GS-12543	If a SoundStation IP 7000 conference phone is disconnected and then reconnected to a RealPresence Group system during a multipoint mixed-mode call, the video from the system might freeze.	Restart the RealPresence Group system.
Interop Polycom SoundStation IP 7000	GS-13406	When using a SoundStation IP 7000 conference phone attached to a RealPresence Group system for an audio call, an incoming video call to the RealPresence Group system might result in the audio call being put on hold with no way of retrieving or hanging up the call.	
Interop Polycom SoundStation IP 7000	GS-21059	When a RealPresence Group system is in a call with a SoundStation IP 7000 conference phone and places the call on hold, only the video is held. The audio is still active.	

Polycom RealPresence Group Series Release Notes

Category	Issue ID	Description	Workaround
Interop Polycom SoundStation IP 7000	GS-25764	When using a SoundStation IP 7000 conference phone connected to a RealPresence Group system to make a video call and an then audio call, if the video call is disconnected, the local interface shows no active calls. You must disconnect the active audio call using the SoundStation IP 7000 phone.	
Interop Polycom Touch Control	GS-14978	If you attempt to pair a Polycom Touch Control and a RealPresence Group system before finishing the setup wizard, a login failed error message might display on the Polycom Touch Control.	Finish the setup wizard on the RealPresence Group system before attempting to pair it with a Polycom Touch Control.
Interop Polycom Touch Control	GS-15219	A Polycom Touch Control might not automatically get a new IP address when switching to a different DHCP server.	Turn the Polycom Touch Control off and back on.
Interop Polycom Touch Control	GS-25908	The Download and Install Software button on the Polycom Touch Control web interface might be grayed out and cannot be selected.	On the Polycom Touch Control screen, touch the Download and Install Software button.
Interop Polycom Touch Control	GS-25992	If during the setup wizard for Polycom Touch Control you skip the pairing screen, you receive an error message about a failure in Directory Provider. You can dismiss the message and continue the setup process, but you will continue to see the error message after each system restart until the Polycom Touch Control is paired.	Do not skip the pairing screen or dismiss the error message. Pair the Polycom Touch Control with a RealPresence Group system.
Interop Polycom VisualBoard	GS-14553	When using the VisualBoard application, monitor 2 shows black video if the resolution is set to 1080i60.	Configure monitor 2 to use 1080p60.
Interop Polycom VisualBoard	GS-15621	NTFS formatted USB flash drives are not supported with VisualBoard.	Use FAT or FAT32 formatted USB flash drives.
Interop Polycom VisualBoard	GS-15734	When VisualBoard content is shared between endpoints in a call and one endpoint is using a 1080p monitor while the other endpoint is using a 720p monitor, the border around the content window will display multiple times.	Ensure both endpoints are using a 1080p monitor.
Interop Polycom VisualBoard	GS-23505	While using the VisualBoard application, you may occasionally see an unexpected Save icon in the toolbar area.	

Category	Issue ID	Description	Workaround
Interop Polycom VisualBoard	GS-23510	You may occasionally see arrows on the right-bottom corner of the VisualBoard application toolbar.	Reconnect the USB storage device.
Interop Polycom VisualBoard	GS-22879	Tapping a single point while the VisualBoard application is calibrating may occasionally end the calibration process.	Restart the calibration process.
Interop Radvision	GS-2160	When in a mixed H.323/SIP call with a Radvision Scopia XT1000 as the MCU, the RealPresence Group system that connected as a H.323 endpoint does not transmit video.	Make the call using either H.323 or SIP.
Interop Radvision	GS-13522	The RealPresence Group Series systems do not receive video from the Radvision Scopia 100 P10 gateway.	
Interop Radvision	GS-13892	When a RealPresence Group Series system is configured for UDP/BFCP and dials into a Radvision Scopia Elite bridge, the content stream is not always negotiated. Instead, content is sent over the people channel.	Use TCP/BFCP in this environment.
Interop Radvision	GS-17405	When a RealPresence Group system and a Radvision Scopia XT1000 are registered to a DMA, and the RealPresence Group system starts sending content before the Radvision system does, the Radvision system cannot send content.	Stop sending content from the RealPresence Group system, and then start sending content from the Radvision Scopia XT1000 system.
Interop RP Resource Manager	GS-24332	If a RealPresence Group system is dynamically managed by RealPresence Resource Manager and the host name of the RealPresence Group system is longer than 64 bytes, logging in through the web interface may fail.	Make sure the host name of the RealPresence Group system, including the domain, is less than 64 bytes.
Interop RP Touch	GS-24738	An error message is not displayed when a USB storage device is removed from a RealPresence Touch before logs are completely transferred to the USB storage device. However, when the USB storage device is removed, the RealPresence Touch displays a message that log transfer was successfully completed.	Wait until the "Log transferred successfully" message is displayed on the RealPresence Touch screen before removing the USB storage device.

Polycom RealPresence Group Series Release Notes

Category	Issue ID	Description	Workaround
Interop RP Touch	GS-24781	A RealPresence Touch paired with a RealPresence Group system sometimes becomes unpaired and is unable to automatically repair.	On the system web interface, go to Admin Settings > General Settings > Pairing > Polycom Touch Device and click Forget this Device . Then on the RealPresence Touch device, repair the system.
Interop RP Touch	GS-22650	Logging out of the RealPresence Touch web interface does not function properly in a Firefox or Chrome browser.	Clear the browser cache or use a different browser, such as Internet Explorer.
Interop RP Touch	GS-23570	You cannot download RealPresence Group system logs from the embedded RealPresence Touch administration page.	Open a web browser and navigate to the RealPresence Group system web interface to download system logs.
Interop RP Touch	GS-29091	A RealPresence Touch device may not present content status on monitors connected to a RealPresence Group system.	
Interop RP Touch	GS-30630	When a RealPresence OTX Studio video call is hung up, but the system is still in an audio call with an RMX bridge, the People and Content Virtual Monitor icon disappears from the RealPresence Touch user interface.	
Interop RP Touch	GS-31873	After upgrading a RealPresence Group system that has an admin password enabled, a RealPresence Touch device does not automatically pair with the system.	
Interop TANDBERG	GS-601	Content does not work when a RealPresence Group system is in a SIP call with a Tandberg MXP system.	Instead of using the SIP protocol, use H.323.
Interop Tely Labs	GS-25617	BFCP negotiation fails when a RealPresence Group 300 system receives SIP calls from a Tely HD system.	
Logging	GS-21913	Users can enter special characters into a CSR field and receive no notification of an invalid entry on RealPresence Group systems. This results in a certificate request failure.	

Polycom RealPresence Group Series Release Notes

Category	Issue ID	Description	Workaround
Monitors	GS-8188	On the RealPresence Group 700 system, the output display is always black when Monitor 1 is a VGA monitor with a Sleep setting of No Signal. If Monitor 2 and Monitor 3 are VGA monitors and the Sleep setting is No Signal, the system does not send a signal to those monitors when it goes to sleep.	
Monitors	GS-23998	Some Philips VGA monitors may display distorted images on RealPresence Group systems.	
Monitors	GS-25845	After a softupdate, displays might remain on if the sleep timer is set to less than three minutes.	Do not set the codec sleep timer to less than three minutes.
Monitors	GS-28171	On RealPresence Group 300 and 310 systems, the touch user interface is not enabled by default.	In the system's web interface, activate the dual monitor option.
Monitors	GS-28149	On some touch monitors, the USB connection is disabled when the display goes into sleep mode. This results in the touch monitor not being recognized by the RealPresence Group system when it comes out of sleep mode, or when it is powered up. To fix this issue, disconnect the monitor from the RealPresence Group system and then reconnect it. Alternately, power off and on the touch monitor.	If possible, deactivate the USB sleep configuration on the touch monitor.
Multipoint	GS-452	RealPresence Group systems do not support Conference on Demand.	
Network	GS-25875	In a call between two RealPresence Group systems in a UNIFY environment with IPV6, BFCP negotiation might fail if the call exceeds two and a half minutes.	
Remote Control	GS-15678	These 6 buttons found on the HDX remote control do not function with a RealPresence Group system: <ul style="list-style-type: none"> - Play - Stop - Pause - Record - Forward - Rewind 	Use the API button command.

Category	Issue ID	Description	Workaround
Security	GS-21618	When SSH is disabled on the RealPresence Group system, connection is still allowed to enter username and password. This is not consistent with Telnet operation. Entering a password does give the correct Access Denied notification with SSH disabled.	
Setup Wizard	GS-8140	When enabling 802.1x authentication using the setup wizard, the only indication that invalid credentials were entered is that the RealPresence Group system has no IP address.	Verify that the credentials you enter are correct.
Setup Wizard	GS-13961	When running the setup wizard on a RealPresence Group system, a VGA component monitor is not detected automatically.	
SIP	GS-11823	In some multipoint SIP calls, the RealPresence Group system might not display video.	Make sure H.239 (dual-stream content) is enabled.
Software Update	GS-16450	The RealPresence Group 700 system with hardware version 7 supports software versions 4.1.3 and higher. However, if a previous version of software is installed using the factory restore method, the conference link no longer works.	Install software version 4.1.3 or higher.
Software Update	GS-25821	When the RealPresence Touch platform software is downgraded using a USB device or using the Polycom link, the downgraded software version is installed with the factory restore image.	
USB	GS-8186	The RealPresence Group 700 system only supports USB factory restore or downgrade from the front panel USB. Restoring or downgrading the system from the rear panel USB port is not supported.	Use the front panel USB port to perform a factory restore or downgrade.
USB	GS-24467	Only one USB storage device can be connected to one host port on a RealPresence Group system, whether it is connected directly or through a hub.	

Category	Issue ID	Description	Workaround
USB	GS-25071	If you have accessed content from a USB storage device while in MSM mode, and then start a new VisualBoard application session, you may sometimes see the content from the USB storage device from the previous session although the USB storage device is no longer connected.	
User Interface	GS-14652	The Recent Calls list might show multiple entries for a failed call to a directory entry.	
User Interface	GS-15307	If an admin password entry is added and then removed, the Admin Settings screen in the local interface displays the lock icon and prompts for credentials.	Enter a user name, but leave the password field empty.
User Interface	GS-22702	On a Lync client, you might see incorrect presence information.	
User Interface	GS-22730	After terminating a call that used video mute, you might continue to see the video mute icon on the secondary monitors.	
User Interface	GS-23231	The layout screen on the local interface of RealPresence Group systems may take a few seconds to open during a call.	
User Interface	GS-23744	After completing the setup wizard, you might see the Hello screen flash with hear sound before the logon screen appears.	
User Interface	GS-23862	If the monitor display is set to No Signal and the RealPresence Group system is set to go to sleep by pressing and holding the hangup button, and you manually put the system to sleep using the remote control, you will not see a notification that the system is going to sleep.	
User Interface	GS-25718	When you change the software update server address and then click the Cancel button on the Polycom Touch Control web interface, you may not always receive a response.	

Polycom RealPresence Group Series Release Notes

Category	Issue ID	Description	Workaround
User Interface	GS-25740	Occasionally when RealPresence Group 500 systems terminate a call, you may see the user's system name and extension as separate headline messages.	
User Interface	GS-25816	Sometimes, a RealPresence Group system microphone may not display a green indicator when the system is in a multipoint call and the call is placed on hold or resumed.	
User Interface	GS-25894	You cannot update the Auto Answer Point-to-Point Video and Auto Answer Multipoint Video settings on the Polycom Touch Control web interface.	Use the RealPresence Group system web interface to update the Auto Answer Point-to-Point Video and Auto Answer Multipoint Video settings.
User Interface	GS-28148	On some touch monitors, the virtual keyboard may not display during a call on RealPresence Group 500 and 700 systems.	Hang up and redial the call.
Video	GS-24169	An EagleEye Producer with an EagleEye III camera and a RealPresence Group 300 or 500 system does not display video after running the setup wizard and changing NTSC to PAL in the RealPresence Group system user interface.	Power down the codec, disconnect and reconnect the EagleEye Producer HDCI cable, and then power up codec up.
Video	GS-22113	When people move around in the room, you may experience stuttering video.	On the web interface, go to Admin Settings > Network > IP Network > Network Quality . Uncheck Automatically Adjust People/Content Bandwidth and set the Quality Preference to Both .
Video	GS-22112	Jagged diagonal lines might appear on the far end's center and right displays.	On the web interface, set the Power Frequency to match the regional setting. For example, for countries with power frequency 50, set the Power Frequency to 50. Go to Admin Settings > Audio/Video > Video Inputs > General Camera Settings > Power Frequency .
Video	GS-22127	The video aspect ratio for a Polycom HDX system is different from the other participants when a Sony XG80 participates in a multipoint call hosted by a RealPresence Group system.	

Polycom RealPresence Group Series Release Notes

Category	Issue ID	Description	Workaround
Video	GS-22794	If the network cable is unplugged and the RealPresence Group system is rebooted, you may see black video for about 20 seconds while the RealPresence Group system looks for the network.	
Video	GS-24574	If you terminated a just initiated call and promptly dialed another call, the far end system might not see the secondary and tertiary video from the near end system.	
Video	GS-25694	In a UNIFY environment with a RealPresence Group system as MCU and a Polycom VVX phone is one of the participants, the RealPresence Group system may send black and white video.	
Video	GS-25738	If the RealPresence Group system participant in an internally hosted multipoint call switches between held calls, erratic video behavior may occur.	
Video	GS-25899	In a UNIFY environment, you may sometimes experience pixelated video on RealPresence Group systems when the RealPresence Group system acts as MCU.	
Web Interface	GS-17048	When the RealPresence Mobile application is paired with a RealPresence Group system using SmartPairing, the web interface might not connect to the RealPresence Group system.	
Web Interface	GS-21047	After the initial setup, the RealPresence Group Series system does not display the EagleEye Producer camera type on the system status page.	Close and re-open the RealPresence Group Series system status page.
Web Interface	GS-21532	On the RealPresence Group Series web interface status page, the VisualBoard status is still shown as active after the monitor USB connection is removed from the system.	
Web Interface	GS-24975	The list of participants for a mixed endpoint call with an internal MCU may differ from the Hangup list.	

Polycom RealPresence Group Series Release Notes

Category	Issue ID	Description	Workaround
Web Interface	GS-27829	If you enter an incorrect system password, then change the Lock Port After Failed Login setting in the web interface, the system is locked out after the third password attempt, regardless of the setting value.	
Web Interface	GS-32625	The Maximum Ventilation Option is enabled by default. When the system downgrades to a earlier version, the fan runs at the maximum speed. If this option is not checked and the system downgrades to a lesser version, the fan speed should automatically adjust according to room temperature.	

This document includes known issues for RealPresence Group systems deployed in Avaya, Broadsoft, IBM, Siemens, Microsoft, and Cisco environments. For more information about those environments, refer to the Polycom release notes for those solutions at http://support.polycom.com/PolycomService/support/us/support/strategic_partner_solutions/index.html.

Other Known Issues

Microsoft Office 365

When migrating an Office 365 on-premises account to online, the system's local or web interface may indicate that it is registered when the process has not yet completed on the server end. If a system is not able to make a call after migration, wait a few minutes and try again. The migration process can take 30 minutes or more to complete.

Prior to registering an Office 365 account with a RealPresence Group system that is set to auto configuration, you must make sure the server and proxy addresses have been cleared. If you have entered specific server addresses into the address fields Registrar server and Proxy server at **Admin Settings > Network > IP Network > SIP**, before you change the SIP Server Configuration setting from **Specify** to **Auto**, you must clear the address fields and then click Save. If the server fields are not cleared, SIP registration might fail.

Cn Attribute Searches

RealPresence Group systems do not support `cn` (common name) RealPresence Resource Manager attribute searches. When `cn` searches are performed, the system automatically uses `displayname` instead.

Samsung SyncMaster TA350 Monitor

When a Samsung SyncMaster TA350 monitor is connected to a RealPresence Group system as a second monitor and the **Dual Display** option is enabled in the web interface, the brightness controls on the second monitor do not work. As a workaround, disconnect the HDMI cable from the Samsung SyncMaster TA350 monitor and then reconnect it.

Wireless Mice

Wireless mice that are connected to RealPresence Group systems may not function properly with the VisualBoard application and are not recommended.

Camera 2 and VisualBoard CSC Usage

Camera 2 and the VisualBoard application share a single color space converter (CSC). If a CSC is used for VisualBoard, it cannot simultaneously be used for camera 2 as people.

Hardware and Software Requirements

Integrating a Polycom SoundStation IP 7000 Conference Phone

To integrate a Polycom SoundStation IP 7000 conference phone with a RealPresence Group system, use the following software versions.

SoundStation IP 7000 Phone Software Version	RealPresence Group System Software Version
4.0.11 and Updater 5.0.11	5.1.2, 6.0.0, 6.0.1
4.0.7 and Updater 5.0.5	4.3.0, 4.3.1, 4.3.2, 5.0.0, 5.0.1, 5.0.2, 5.1.0, 5.1.1

SoundStation IP 7000 Phone Software Version	RealPresence Group System Software Version
4.0.6 and Updater 5.0.x	4.2.0
4.0.4 and Updater 5.0.x	4.1.3, 4.1.3.2
4.0.4 and BootRom 5.0.1	4.1.1, 4.1.1.1
4.0.3F and BootRom 5.0.1	4.0.1, 4.0.2
4.0.2 Revision B and BootRom 5.0.1	4.0.0, 4.0.0.1

Integrating Polycom Touch Devices

To integrate a RealPresence Touch or Polycom Touch Control with a RealPresence Group system, you must use a compatible software version.

When you downgrade the RealPresence Group Series system software and pair with a Polycom RealPresence Touch system, the software on the RealPresence Touch device is automatically downgraded to a compatible version. However, the RealPresence Touch platform version 2.0 software may not be downgraded automatically to version 1.0. To downgrade from version 2.0 to version 1.0, you must use a USB storage device or manually initiate a downgrade from a server repository that includes version 1.0.

Polycom RealPresence Touch

The RealPresence Touch, after pairing with RealPresence Group Series, verifies the compatibility of the RealPresence Touch panel software and requests a software update. Polycom recommends that you update the software on RealPresence Touch to match the Group Series software. The RealPresence Touch operating system software version does not have to match the RealPresence Touch panel software version, however, Polycom recommends that you use the latest operating system software. The RealPresence Touch operating system software can be updated through the administration pages on the RealPresence Touch or through the RealPresence Touch web interface.

When you downgrade the RealPresence Group Series system software, the Polycom RealPresence Touch software is automatically downloaded to a compatible version after being paired. However, the RealPresence Touch platform version 2.0 might not automatically downgrade to version 1.0. In this case, to manually downgrade from version 2.0 to 1.0, you must use a USB storage device or initiate a downgrade from a server repository that includes version 1.0.

Polycom Touch Control

The first three numbers of the Polycom Touch Control software version must match the first three numbers of the RealPresence Group Series software version. For example, Polycom Touch Control software version 4.1.1 is compatible with RealPresence Group Series software versions 4.1.1 and 4.1.1.1.

Integrating EagleEye Producer

Updates to EagleEye Producer software are included with the RealPresence Group system software updates. To integrate your EagleEye Producer, connect it to the RealPresence Group system before you run a software update. The software update program detects the EagleEye Producer and updates it if necessary. No license number or key code is needed to update the EagleEye Producer.

EagleEye Producer must run a software version that is compatible with the software version on the RealPresence Group system to function properly. EagleEye Producer version 1.2 is compatible with version

6.0.0 and higher of RealPresence Group Series. For more information, refer to the current Polycom Supported Products matrix at Polycom Service Policies.

Interoperability

Video conferencing systems use a variety of algorithms to compress audio and video. In a call between two systems, each end transmits audio and video using algorithms supported by the other end. In some cases, a system might transmit a different algorithm than it receives. This process occurs because each system independently selects the optimum algorithms for a particular call, and different products might make different selections. This process should not affect the quality of the call.



Note: For more information about using Polycom RealPresence Group Systems as part of a Polycom-partner product solution, refer to the Polycom-partner product deployment guides available at support.polycom.com.

Products Tested in this Release

Polycom RealPresence Group Systems are tested extensively with a wide range of products. The following list is not a complete inventory of compatible equipment. It simply indicates the products that have been tested for compatibility with this release. For Polycom peripherals that are compatible with the RealPresence Group systems, refer to Hardware and Software Compatibility.

Polycom strives to support any system that is standards-compliant and investigates reports of Polycom systems that are not interoperable with other vendor systems.



Note: Polycom recommends that you upgrade all of your Polycom systems with the latest software versions. Any compatibility issues may already have been addressed by software updates. Go to PolycomService/support/us/support/service_policies.html to see the Current Polycom Interoperability Matrix.

Product	Interoperable Versions
Management Systems and Recorders	
Polycom RSS™ 4000	8.5.4
Polycom® RealPresence® Access Director™	4.2.2
Polycom® RealPresence® Media Suite™	2.7
Polycom® RealPresence® Distributed Media Application™ 7000	6.3.2.2
Polycom® RealPresence® Resource Manager	10.0.0
Gatekeeper, Gateways, External MCU, Bridges, Call Managers	
Avaya Aura® Communication Manager	R016x.03.0.124.0
Cisco® TelePresence® Video Communication Server (VCS)	X8.6.1
Cisco Unified Communications Manager	11.5.1

Product	Interoperable Versions
Codian 4505 MCU	4.5 (1.72)
Cisco 3241 Gateway	2.2 (1.106)
Cisco 5310 MCU	4.5 (1.72)
Cisco 8710 MCU	4.2 (4.18)
Polycom® RealPresence® Collaboration Server 1500	8.5
Polycom® RealPresence® Collaboration Server 1800/4000	8.7.1
Polycom® RealPresence® Collaboration Server Gateway	8.6.3.6
Radvision® Scopia® 100 P10 Gateway	5.7.2.1.47
Radvision® ECS Gatekeeper	7.7.0.0.27
Endpoints	
Avaya Aura® Communication Manager	R016x.03.0.124.0
Avaya Aura® Session Manager	6.3.4.0.634014
Avaya Scopia XT5000	8.3.2.534
Avaya Scopia XT7000	8.3.2.225
Cisco 9971	sip9971.9-4-2sr2-2
Cisco C20, C40	7.3.3
Cisco C90	7.3.5
Cisco DX70/DX80/DX650	10-2-4-99
Cisco E20	4.1.7
Cisco EX90	7.3.3
Cisco SX10, SX20	8.0.1
Cisco SX80	8.1.1
Huawei TE40	1.10.100
Huawei TE30	1.2.100
LifeSize® SoftPhone	8.1.12
LifeSize® Express 220	5.0.9
LifeSize® Team 220	5.0.9
LifeSize® ICON 600	2.9.0
LifeSize® Passport	4.12.0

Polycom RealPresence Group Series Release Notes

Product	Interoperable Versions
Polycom HDX Systems	3.1.11
Polycom Concerige Solution	Phase 1
Polycom® RealPresence Centro™	6.0.1
Polycom® RealPresence® Debut™	1.1.0
Polycom® RealPresence® Mobile Android	3.5.1
Polycom RealPresence® Mobile IOS	3.5.1
Polycom® RealPresence® Desktop for Windows®	3.5.1
Polycom® RealPresence® Desktop for Mac®	3.5.1
Polycom® Immersive Telepresence (ITP) Series	3.1.4
Polycom® RealPresence Immersive Studio™	6.0.1
Polycom® RealPresence® OTX® Studio	6.0.1
Polycom® SoundPoint® IP 650	4.0.7
Polycom® SoundStructure®	1.7.2
Polycom® VVX® 300/400/500/600/1500	5.5.0
Radvision Scopia XT1000	2.5.416
Sony PCS-1	3.42
Sony PCS-G50	2.72
Sony PCS-TL50	2.42
Sony PCS-XG80	2.45
Sony PCS-XG100	1.50.20
TANDBERG 1700 MXP	F9.4
TANDBERG Edge95 MXP	F9.4
TANDBERG T150	L6.1
Peripherals	
Polycom EagleEye Producer	1.2.1
Polycom EagleEye Director	2.2

Product	Interoperable Versions
Polycom RealPresence Touch	6.0.1 Panel software 2.0.0 Operating System software
Polycom Touch Control	6.0.1
VisualBoard Application	4.1.3 software and later

Microsoft Interoperability

The RealPresence Group systems support interoperability with the following Microsoft software versions.

Product Name	Version
Microsoft Skype for Business Server 2015	6.0.9319.235
Microsoft Lync Server 2013	5.0.8308.941
Microsoft Exchange Server 2013	15.00.1130.007
Microsoft Skype for Business online	Versions updated regularly and hosted by Microsoft
Microsoft Exchange Server Online	Versions updated regularly and hosted by Microsoft



Note: RealPresence Group Series does not support interoperability with Lync 2010 clients in Internal MCU and AVMCU calls.

Cisco and TIP Interoperability

The RealPresence Group systems support interoperability with the following Cisco equipment and TIP protocols:

- Cisco TelePresence System 1.10.13 interoperability (People video 1080p resolution at 30 Hz; content frame rate for XGA at 5 fps)
- Cisco TelePresence System next generation interoperability with TIP Version 7
- Cisco TX Series Version 6.1.10
- Cisco IX5000 Version 8.0.6
- Cisco TelePresence Server 4.2

The following features are not supported in this release:

- Media encryption through Datagram Transport Layer Security (DTLS) or Standard SRTP (SDS)
- Secure registration to Cisco Unified Communications Manager.

VisualBoard Interoperability

The VisualBoard application is an integrated application that is supported on all Polycom® RealPresence® Group Series systems. If you have not yet enabled the VisualBoard application, refer to the *Polycom RealPresence Group Series Administrator Guide* at support.polycom.com.

Copyright Information

Copyright© 2017, Polycom, Inc. All rights reserved. No part of this document may be reproduced, translated into another language or format, or transmitted in any form or by any means, electronic or mechanical, for any purpose, without the express written permission of Polycom, Inc.

6001 America Center Drive
San Jose, CA 95002
USA

Trademarks Polycom®, the Polycom logo and the names and marks associated with Polycom products are trademarks and/or service marks of Polycom, Inc. and are registered and/or common law marks in the United States and various other countries.



All other trademarks are property of their respective owners. No portion hereof may be reproduced or transmitted in any form or by any means, for any purpose other than the recipient's personal use, without the express written permission of Polycom.

End User License Agreement By installing, copying, or otherwise using this product, you acknowledge that you have read, understand and agree to be bound by the terms and conditions of the End User License Agreement for this product. The EULA for this product is available on the Polycom Support page for the product.

Patent Information The accompanying product may be protected by one or more U.S. and foreign patents and/or pending patent applications held by Polycom, Inc.

Open Source Software Used in this Product This product may contain open source software. You may receive the open source software from Polycom up to three (3) years after the distribution date of the applicable product or software at a charge not greater than the cost to Polycom of shipping or distributing the software to you. To receive software information, as well as the open source software code used in this product, contact Polycom by email at OpenSourceVideo@polycom.com.

Disclaimer While Polycom uses reasonable efforts to include accurate and up-to-date information in this document, Polycom makes no warranties or representations as to its accuracy. Polycom assumes no liability or responsibility for any typographical or other errors or omissions in the content of this document.

Limitation of Liability Polycom and/or its respective suppliers make no representations about the suitability of the information contained in this document for any purpose. Information is provided "as is" without warranty of any kind and is subject to change without notice. The entire risk arising out of its use remains with the recipient. In no event shall Polycom and/or its respective suppliers be liable for any direct, consequential, incidental, special, punitive or other damages whatsoever (including without limitation, damages for loss of business profits, business interruption, or loss of business information), even if Polycom has been advised of the possibility of such damages.

Customer Feedback We are striving to improve our documentation quality and we appreciate your feedback. Email your opinions and comments to DocumentationFeedback@polycom.com.

Polycom Support Visit the [Polycom Support Center](#) for End User License Agreements, software downloads, product documents, product licenses, troubleshooting tips, service requests, and more.